

TITLE SCREEN of RXB (explanations)	PAGE 1
SPECIAL FEATURES OF RXB (explanations)	PAGE 2

MOVE	COMMAND	LINES	M3
MOVES	SUBPROGRAM	MEMORY (ALL)	M4
NEW	SUBPROGRAM or COMMAND	MEMORY (XB)	N1
ONKEY	SUBPROGRAM	KEYBOARD	O1
PEEK	SUBPROGRAM	GROM	P1
PEEKV	SUBPROGRAM	VDP	P2
POKE	SUBPROGRAM	GRAM	P3
POKER	SUBPROGRAM	VDP REGISTERS	P4
POKEV	SUBPROGRAM	VDP	P5
PROTECT	SUBPROGRAM	DISK or HARD DRIVE	P6
QUITOFF	SUBPROGRAM	KEYBOARD	Q1
QUITON	SUBPROGRAM	KEYBOARD	Q2
RENAME	SUBPROGRAM	DISK or HARD DRIVE	R1
RES	COMMAND	LINES	R2
RMDIR	SUBPROGRAM	DISK	R3
RMOTION	SUBPROGRAM	SPRITE	R4
RND	SUBPROGRAM	CONVERSION	R5
SAVE	COMMAND	DISK or HARD DRIVE	S1
SCSI	SUBPROGRAM	SCSI CONTROLLER	S2
SECTOR	SUBPROGRAM	DISK or HARD DRIVE	S3
SIZE	SUBPROGRAM or COMMAND	MEMORY (ALL)	S5
SWAPCHAR	SUBPROGRAM	SCREEN	S6
SWAPCOLOR	SUBPROGRAM	SPRITE	S7
USER	SUBPROGRAM	DISK	U1
VCHAR	SUBPROGRAM	SCREEN	V1
VERSION	SUBPROGRAM	GROM RXB	V2
VGET	SUBPROGRAM	SCREEN	V3
VPUT	SUBPROGRAM	SCREEN	V4
XB	DSR or SUBPROGRAM	DEVICE	X1
XBPGM	SUBPROGRAM	DISK or HARD DRIVE	X2

This is a copy of the RXB title screen:

```
*****
* VERSION = 2015 *
*****
*      R X B      *
*                *
*      creator    *
*                *
* Rich Gilbertson *
*****

>> press ===== result <<

ANY KEY = DSK#.LOAD

ENTER   = DSK#.UTIL1

(COMMA) , = DSK#.BATCH

SPACE BAR = RXB COMMAND MODE

(PERIOD) . = EDITOR ASSEMBLER
```

NOTE: 0 (ZERO) defaults to WDS1.LOAD or after pressing

ENTER defaults to WDS1.UTIL1

This is a explanation of the keys of the MENU screen:

(any key) = DSK#.LOAD

While the screen shows menu RXB is selected pressing any key will be the drive that DSK#.LOAD will be run from. RAMDISK number keys 1 to 9 or the alpha keys A to z. Pressing 0 (zero) key will run WDS1.LOAD

(ENTER key) = DSK#.UTIL1

While the screen shows menu RXB is selected pressing ENTER key switches to the REA module and goes to Editor Assembler run program file DSK#.UTIL1 so select number.

(COMMA) , = DSK#.BATCH

While the screen shows menu RXB is selected pressing COMMA key runs DSK#.BATCH DSK#.BATCH defaults to DSK1 if BATCH not fun will default to command mode. For more information on this feature read USER in the RXB information on BATCH FILE SYSTEM below.

(SPACE BAR) = RXB COMMAND MODE

Pressing the SPACE BAR results in XB command mode.
(Same as waiting a few seconds just like normal XB does.)

(PERIOD) . = EDITOR ASSEMBLER

Pressing the . (PERIOD) key will switch to EDITOR ASSEMBLER menu. Pressing the . (PERIOD) key while in EDITOR ASSEMBLER will switch back to RXB.

(ZERO) 0 = WSD1.LOAD

Pressing the 0 (ZERO) key will start a WSD1.LOAD to execute from hard drive 1. If the root directory has a LOAD program. If a SCSI drive or Myarc HFDC exists at the lowest CRU address it will load WDS1.LOAD (Both cards have WDS1 in device list.)

DISK AND HARD DRIVE ACCESS

CALL CAT catalog disk or hard drives.
 CALL DIR catalog disk or hard drives. (Requested duplicate of CAT)
 CALL FILES same as disk controller version but executes new after.
 CALL FCOPY copy's a file from device to device.
 CALL PROTECT protects or unprotects a file.
 CALL RENAME renames a file or directory.
 CALL MKDIR makes a directory on hard drives or names disks.
 CALL RMDIR deletes a directory on hard drive.
 CALL CUTDIR deletes a directory and all sub-directories.
 CALL SECTOR reads or writes disk or hard drive sectors.
 CALL XBPGM not only runs XB programs but does a CALL FILES first.
 CALL SCSI retrieves the scuzzy device ID codes. The info will contain the device company name, version number, revision number and size. Example XB program provided in SCSI documents.

BATCH FILE SYSTEM:

CALL USER overrides the normal edit mode by allowing a DV80 file to take control. This allows conversions from DV80 to XB program or DV80 to XB MERGE format or loading files, re-sequencing them, and saving or merging or adding lines through another DV80 file. All variables used through CALL USER are not affected so from a running program more lines or variables can be added to the size of the program without losing anything. Of course the RUN command will as always clear all variables before the program is run, this feature can be turned off with a CALL LOAD. (PRESCAN OFF)
 As the USER subprogram can override the Editor many features can be bypassed. Example:

NEW	cr
OLD DSK1.XBPROGRAM	cr
RES 11,3	cr
MERGE "DSK1.MERGEPM"	cr
SAVE "DSK1.NEWPROGRAM"	cr
RUN	cr

The above is a good example of a DV80 Batch file for RXB. Note that there must be a CHR\$(13) or Carriage Return after every input line. If not then RXB assumes the it is the same line. But even that is not much of a problem as RXB allows 21 lines of input per program line. You can make them even longer if you want.

INPUT/OUTPUT ACCESS:

 CALL IO controls the 9901 CRU chip. Sound lists can be played independently of current status. (i.e. type in a program while playing music from VDP/GROM.) Control Register Unit can turn on/off single bits of CRU address bus. (i.e. cards/chips)
 Cassette direct bus control. (i.e. no menu input/output, verify)

REDO KEY RESTORED:

 The REDO (FCTN 8) is RESTORED in RXB. USER needed a buffer that would not be molested or modified by CALL LINK, CALL LOAD or routines that need a buffer and usually use the same area that USER previously used. So to update and eliminate questions of compatibility the USER buffer was installed in place of the Edit recall buffer (REDO). The REDO key was not considered to be of much use anyway as the Crunch Buffer is 163 tokens long and in non-tokenized form the Edit recall buffer is only 152 bytes long. That is why when REDO is pressed only part of the line last typed in was recalled to screen. Additionally COPY lines, and MOVE lines commands can do the same thing as REDO could, so not much of anything is lost because it is assumed a TEXT EDITOR will be used to create programs in RXB then use CALL USER.

PROGRAM DEVICE NAMES ACCESS:

 New access names established as devices are now available. By using any TRUE DSR (Device Service Routine) you may now access the Editor Assembler main menu by typing 'EA' within Basic or RXB. Example: RUN "EA" or OLD EA or DELETE "EA"
 You may also access RXB from Editor Assembler or Basic or even another cartridge. Example: OLD XB or DELETE "XB" from Basic.
 At any Editor Assembler device prompt type 'XB' then enter.

FOR ASSEMBLY LANGUAGE PROGRAMMERS:

 CALL MOVES is a new command that is a GPL command converted and added to RXB to give total control over every type of memory with in the TI-99/4A. MOVES works with address or strings to copy, over-write or move blocks of memory of any type of memory. RAM, VDP, GROM, GRAM, and ROM can be accessed by CALL MOVES.

RXB TO ASSEMBLY DIRECT ACCESS BY ADDRESS:

EXECUTE is much faster than the traditional LINK routine built into XB. The main problem with LINK is it checks everything and pushes everything onto the VDP stack. After getting to Assembly it pops everything off the stack for use or pushes what is to be passed to XB onto the stack. EXECUTE on the other hand just passes a address to a 12 byte Assembly program in Fast RAM and RTWP ends the users program. A LINK will use up 6 bytes for the name, 2 bytes for the address and wastes time checking things. The advantage to EXECUTE is you use LOAD or MOVE or MOVES to place the values needed directly into the registers then do it. EXECUTE uses less space, is faster, and is easy to debug.

AMS SUPPORT ROUTINES:

The AMS now has support routines built into RXB. CALL AMSMAP will turn the AMS mapper on. CALL AMSPASS will turn the AMS mapper back to pass mode. CALL AMSON will turn on the read/write lines of the mapper. CALL AMSOFF will turn off the read/write lines. With these commands pages of memory can be written with a CALL LOAD or read with a CALL PEEK. Also little known by users is the fact that if a RXB program is smaller than 10K it can be run from VDP not the upper 24K. So paging the upper or lower memory of the AMS is possible from RXB programs. RXB AMS SUPPORT USES NO ASSEMBLY OR CALL LINKS. That means up to 1meg of lower 8K pages or upper 24K pages from RXB. That is impossible to do from XB as you have to load your normal support somewhere.

GPL is where all the support routines are stored in RXB so not one byte is wasted on assembly support. That also means not one byte of AMS memory is wasted on control routines.

Speaking of control CALL AMSINIT initializes the mappers and switches the AMS to map mode. CALL AMSBANK switches 4K pages in the lower half and upper half of the lower 8K.

AMSBANK is a built in AMS memory bank switcher for the lower 8K.

RND FUNCTION REPLACED

Extended Basic RND has been replaced with the TI BASIC RND as the normal XB version of RND was hindered by too much Floating Point that is very slow for use just to get a random number. Also the XB RND was insanely complicated and bloated.

INTERRUPT SERVICE ROUTINE CONTROL (ISROFF and ISRON)

ISR (Interrupt Service Routine) like MOUSE or Screen dumps or any special program like XB Packer use a ISR. The problem with these programs is unless they are written to work with new devices, a lock-up occurs. EXAMPLE: running a mouse routine and XB Packer. They were never made to work together. RXB now has a handle on this. CALL ISROFF turns off the interrupt and saves the address for turning it back on. CALL ISRON restarts the interrupt. As several pages of the AMS can be used with interrupts a whole new world of programming is now possible.

NO ASSEMBLY IS USED OR CALL LINKs. Absolute compatibility.

LOWER 8K PROGRAM IMAGE FILE LOADER AND SAVER (BLOAD and BAAVE)

Hidden loaders were created to overcome the slow loading speed of CALL LOAD. The disadvantage of a hidden loader is it can only load one assembly support program at a time. BLOAD loads program image files of the lower 8K, and BLOAD can load as many times as needed within one RXB program. BSAVE is the opposite and creates the program image files of the lower 8K support routines. Lastly loading 200K into the AMS card is easy with BLOAD and AMSBANK. A simple loop can load each AMS 8K bank with AMSBANK and BLOAD loads 8K at a time into the lower 8K.

SAVE FILES IN INTERNAL VARIABLE 254 OR PROGRAM IMAGE FORMAT

RXB allows XB programs to load or be saved in two formats as previously, but now RXB allows more control of this feature. Normally XB will save files in Program Image format if these programs are small enough to fit in VDP memory. If these XB programs are larger then what will fit in VDP then XB programs will be saved in Internal Variable 254 format. RXB has a added feature added to save command. IV254 is the new feature.

EXAMPLE: SAVE DSK3.TEST,IV254

Format CALL AMSBANK(page-number,page-number)

 CALL AMSBANK(numeric-variable,numeric-variable)

Description

The AMSBANK command will only work with a AMS memory card. AMSBANK turns on the read/write lines of AMS mapper registers stores the first value into the mapper register that sets low half of lower 8K, then stores the second value into the mapper register that sets high half of lower 8K. If the page-number is less then 0 or larger than 239 a BAD VALUE error results. If page-number is larger than the AMS card size allows * AMS BANK NUMBER ERROR * results. Neither error will affect previously loaded pages. No lock-up will result.

AMSBANK breaks the lower 8K into two halves of 4K. The lower 4K is Hex >2000 to >2FFF and the upper is Hex >3000 to >3FFF so switching lower 8K requires two 4K pages to be used. This is the only disadvantage to AMSBANK, but flexibility does result. Less wasted pages results in more memory available. The formula is: AMS SIZE/4-16=pages.

EXAMPLE: 256/4-16 is 48 pages.

In other words 0 to 15 pages would be 16 pages for use. The odd ball numbering scheme of AMSBANK results from pages 0 to 15 not being used in MAP mode. AMSBANK creates it's own numbers of pages 0 to 239 by starting actually at page 16 of the AMS. That would be page 0 of AMSBANK. This lay out leaves open 8 4K pages for PASS mode, and 8 4K pages for future use. See docs MANUAL-AMS for additional information.

Programs

This sets up & starts map model | >100 CALL AMSINIT
This turns on the AMS mapper. | >110 CALL AMSON
This reads low half 8K page. | >120 CALL PEEK(16388,L)
This reads high half 8K page. | >130 CALL PEEK(16390,H)
This shows pages used. | >140 PRINT "LOW";L;"HIGH";H
This loads a assembly program. | >150 CALL LOAD("DSK1.CHAR")
This changes low/high 8K pages | >160 CALL AMSBANK(16,17)
This loads a assembly program. | >170 CALL LOAD("DSK1.DUMP")
This changes low/high back. | >180 CALL AMSBANK(L,H)
This uses a routine in CHAR. | >190 CALL LINK("CHAR")
This changes low/high again. | >200 CALL AMSBANK(16,17)
This uses a routine in DUMP. | >210 CALL LINK("DUMP")
|

The above example program shows one RXB program using two assembly programs with links for both. Thus only 16K of the AMS was used. 1024K would be 120 assembly support programs
Compatibility of most software assured in RXB AMS support.

Format CALL AMSINIT

Description

The AMSINIT command will only work with a AMS memory card. AMSINIT turns on the read/write lines of AMS mapper registers stores pages 0 to 15 into mapper registers, then turns on MAP mode. Essentially PASS mode and MAP mode are the same in that the mapper registers are exactly the same in both modes. That means in both modes the same memory is used. This would make the AMS of little use so LOAD is used to change mapper registers and switch pages. But if upper memory is switched from a XB program the page that just did this is switched out and a lock-up occurs. On the other hand switching pages in the lower 8K presents very few problems. So see AMSBANK. AMSINIT can also be used like AMSPASS but stays in MAP mode. See docs MANUAL-AMS for examples of memory maps.

Programs

```
This sets up & starts map model >100 CALL AMSINIT
This turn on the AMS mapper. | >110 CALL AMSON
This reads low half 8K page. | >120 CALL PEEK(16388,L)
This reads high half 8K page. | >130 CALL PEEK(16390,H)
This shows pages used.       | >140 PRINT "LOW";L;"HIGH";H
This changes low half 8K page. | >150 CALL LOAD(16388,16)
This changes high half 8K page | >160 CALL LOAD(16390,17)

This sets up & starts map model >200 CALL AMSINT
This turns on the AMS mapper. | >210 CALL AMSON
This reads low half 8K page. | >210 CALL PEEK(16388,L)
This reads high half 8K page. | >220 CALL PEEK(16390,H)
This shows pages used.       | >230 PRINT "LOW";L;"HIGH";H
This changes low/high 8K pages | >240 CALL AMSBANK(16,17)
|
```

In the above program 100 to 160 and 200 to 220 do the same thing. Using CALL AMSBANK is more effective than using a CALL LOAD to change mapper registers as a CALL AMSON is needed to turn on the mappers to be written or read. When using the AMS with RXB it is suggested to always use CALL AMSBANK to change pages as it is less complicated and faster with less wasted program lines. EXAMPLE:

```
This line sets up AMS memory.  | >100 CALL AMSINIT
This line loads AMS pages 0,1. | >110 CALL AMSBANK(0,1)
This line loads a program.     | >120 CALL LOAD("DSK1.TEST")
This line loads AMS pages 2,3 | >130 CALL AMSBANK(2,3)
This line loads a program.     | >140 CALL LOAD("DSK1.JUNK")
```

Example program to ZERO out the entire AMS Memory 1 Meg:

```
Initializes AMS memory.      | >100 CALL AMSINT
This line sets up a loop count | >110 FOR M=1 TO 238 STEP 2
This line loads AMS banks     | >120 CALL AMSBANK(M,M+1)
This line zeros byte at >2000 | >130 CALL LOAD(8292,0)
This line ripples that zero   | >140 CALL MOVES("RR",8191,
8191 times                    | 8192,8193)
This line resets loop counter | >150 NEXT M
This line end program         | >160 END
```

Format CALL AMSMAP

Description

The AMSMAP command will only work with a AMS memory card. MAP MODE on the AMS card means the mapper registers are turned on so they can be changed. But even with the mapper on unless the read/write lines are on no mappers will appear to be at the DSR address. AMSON turns on read/write mapper registers. Then a LOAD or AMSBANK can change the memory pages. See docs MANUAL-AMS for examples of memory maps. Also run AMS-TEST or AMS-SAVE or AMS-LOAD programs.

Programs

```
This turns on map mode.           | >100 CALL AMSMAP
This turns on read/write.       | >110 CALL AMSON
This fetches map register 2.    | >120 CALL PEEK(16388,BYTE)
This turns off read/write.     | >130 CALL AMSOFF
This turns on pass mode.       | >140 CALL AMSPASS
This prints the page from map   | >150 PRINT "Register 2 PAGE#"
mode in register 2.            |   ;BYTE
                                  |
```

The above program will print out whatever AMS page is presently stored in AMS map register 2.

It is recommended that CALL AMSMAP only be used to check AMS pages with CALL PEEK. CALL AMSBANK is much more easy to use to manage AMS memory.

Format CALL AMSOFF

Description

The AMSOFF command will only work with a AMS memory card. The read/write lines to the AMS mapper registers are turned off so they will not be changed. Any PEEK or LOAD to the DSR space will be zero after the AMSOFF command. They can't be read/written to. See docs MANUAL-AMS for examples of memory maps. Also run AMS-TEST or AMS-SAVE or AMS-LOAD programs.

Programs

```
This sets up & starts map model >100 CALL AMSINIT
This turns on read/write.     | >110 CALL AMSON
This fetches map register 2. | >120 CALL PEEK(16388,BYTE)
This turns off read/write.   | >130 CALL AMSOFF
This turns on pass mode.     | >140 CALL AMSPASS
This prints the page from map | >150 PRINT "Register 2 PAGE#"
mode in register 2.           | ;BYTE
                              |
```

The above program will print out initialized AMS page 2 in register 2.

It is recommended that CALL AMSOFF only be used to protect the AMS mapper registers from being molested by programs that could access the AMS. CALL AMSBANK is more easy to use to manage AMS memory as AMSBANK always turns off the AMS read/write registers like AMSOFF does. Instead use AMSBANK.

Format CALL AMSON

Description

The AMSON command will only work with a AMS memory card. The read/write lines to the AMS mapper registers are turned on so they can be changed. Any PEEK or LOAD to the DSR space can then be used to change the mapper registers or read them. See docs MANUAL-AMS for examples of memory maps. Also run AMS-TEST or AMS-SAVE or AMS-LOAD programs.

Programs

```
This sets up & starts map model >100 CALL AMSINIT
This turns on read/write.      | >110 CALL AMSON
This loads 9 in map register 2| >120 CALL LOAD(16388,9)
This turns off read/write.    | >130 CALL AMSOFF
This loads values in lower 8K.| >140 CALL LOAD(8192,1,2,3,4)
This turns on pass mode.      | >150 CALL AMSPASS
This peeks values in lower 8K.| >160 CALL PEEK(8192,A,B,C,D)
This prints values.           | >170 PRINT A;B;C;D
This turns on map mode.       | >180 CALL AMSMAP
This turns on read/write.     | >190 CALL AMSON
This loads 2 in map register 2| >200 CALL LOAD(16388,2)
This turns off read/write.    | >210 CALL AMSOFF
This peeks values in low page.| >220 CALL PEEK(8192,A,B,C,D)
This prints values.           | >230 PRINT A;B;C;D
                                |
```

It is recommended to use CALL AMSON only for when a CALL PEEK is used to check a mapper register value. CALL AMSBANK manages AMS mapping much better.

Format CALL AMSPASS

Description

The AMSPASS command will only work with a AMS memory card. PASS MODE on the AMS card means the mapper registers are not on. This is the normal mode of the AMS. No extra memory is available or used. This renders the AMS like a normal 32K card. See docs MANUAL-AMS for examples of memory maps. Also run AMS-TEST or AMS-SAVE or AMS-LOAD programs.

Programs

```
This sets up & starts map model >100 CALL AMSINIT
This turns on read/write.     | >110 CALL AMSON
Load 22 into map register 2.  | >120 CALL LOAD(16388,22)
This turns off read/write.    | >130 CALL AMSOFF
This turns on pass mode.      | >140 CALL AMSPASS
                               |
```

AMSPASS is mainly used to turn off AMS or protect the AMS pages from being used or to behave like a normal TI99/4A when the AMS is not being used.

Please note that AMSBANK does not use the AMSPASS memory so this area stays protected. This is by design in RXB.


```
Format          RUN "BASIC"
                DELETE "BASIC"
                CALL XBPGM("BASIC")
                CALL CAT("BASIC")
                OLD BASIC
                CALL BASIC
```

Description

The BASIC DSR (Device Service Routine) allows access to the TI BASIC . The access will work only if the DSR is the GPLDSR or LINK DSR. In other words, a DSR that acknowledges any type of DSR in RAM, ROM, GROM, GRAM, or VDP. Most DSR's only accept DSK or PIO. Others like the SAVE or LIST commands will only work with a program in the memory first. Still others like CALL LOAD("EA") must have the CALL INIT command used first.

Keep in mind that if it does not work, the problem is the DSR your using. Almost all DSR's today only acknowledge the ROM or RAM DSR's. As the BASIC DSR is in GROM/GRAM it seems a bit short sighted on the part of most programmers to use cut down versions of a DSR. Please discourage this practice as it is a disservice to us all.

Programs

Will go to BASIC prompt	>100 CALL XBPGM("BASIC")
This line asks for a string.	>100 INPUT A\$
If string A\$="BASIC" will go	>110 DELETE A\$
will switch to BASIC.	
Will switch to BASIC.	>CALL BASIC
Lower case also works!	>CALL EAPGM("basic")

Format CALL BEEP

Description

The BEEP command produces the same sound as the ACCEPT or INPUT, or BEEP as in DISPLAY options.
See EXTENDED BASIC MANUAL pages 47, 48, 49, 77, 78.

Programs

The program to the right will | >100 CALL BEEP
will produce a beep sound. |
Show request. | >110 PRINT "YNyn ?"
Key press request. | >120 CALL KEY("YNyn",0,K,S)

The above program will BEEP then wait for a key and only accept Y N y n from CALL KEY into K.

Format CALL BIAS(numeric-variable,string-variable
 [,...])

Description

The BIAS command adds 96 to all characters in the string or subtracts 96 from all characters in the string. If numeric variable is 0 then it subtracts the XB screen bias of 96 from the characters, if the numeric variable is not 0 then it adds the XB screen bias of 96 to all the characters in the string. ONLY A STRING VARIABLE IS ALLOWED.

The XB screen bias only affects characters read or written to the screen. See PEEKV, and POKEV.

Programs

```
The program to the right will | >100 CALL MOVES("V$",255,511
load X$ with 255 characters   | ,X$)
off the screen. But will not |
be readable due to a bias.   |
The bias is now subtracted   | >110 CALL BIAS(0,X$)
from the string printed.     | >120 PRINT X$
                             |
```

The above program copies 255 bytes from screen address 511 (511=15 rows plus 31 columns) into string X\$. Then BIAS removes 96 from each byte in string X\$. Finally X\$ is shown on screen by PRINT X\$

Format CALL BLOAD("access-name")

 CALL BLOAD(string-variable)

Description

The BLOAD subprogram loads ONLY program image files created by BSAVE. BLOAD is the opposite of BSAVE. BLOAD is a faster version of CALL LOAD. BLOAD has the speed of a hidden loader and is much easier to use. BLOAD only loads into lower 8K.

Unlike CALL LOAD the BLOAD and BSAVE subprogram will work without CALL INIT being used first. Remember to turn on the interrupts if the program has them. Or the program support will not work. See ISROFF and ISRON.

NOTE: 8K of VDP memory MUST be free for BLOAD to function or a memory full error will result. Always place the BLOAD command at the top of the RXB program.

Programs

```
This line loads a previously | >100 CALL BLOAD("DSK2.MOUSE")
saved program image file.   |
This line turns on the mouse | >110 CALL LINK("MSON")
(program would continue here)|
|
This line load a previously | >100 CALL BLOAD("DSK1.DUMP")
saved program image file.   |
This line turns on interrupt | >110 CALL ISRON(16384)
within program.             |
This line links to support.  | >120 CALL LINK("DUMP")
|
```

Options

AMS users will find this a easy way to load RXB AMS support.

EXAMPLE:

```
>100 CALL AMSINIT
>110 FOR L=0 TO 15 STEP 2
>120 CALL AMSBANK(L,L+1)
>130 CALL BLOAD("DSK1.BANK"&STR$(L/2))
>140 NEXT L
>150 CALL XBPGM("DSK1.MAINPROGRAM",1)
```

The above program would load RXB AMSBANK banks 0 to 15 into AMS memory from files named BANK0 to BANK7 on disk 1. Then would set CALL FILES 1 and RUN "DSK1.MAINPROGRAM" with 64K of Assembly support for XB.

See AMSINIT, AMSBANK, ISROFF, ISRON, EXECUTE, and MOVES.

Format CALL BSAVE("access-name")

 CALL BSAVE(string-variable)

Description

The BSAVE subprogram saves ONLY program image files to be used for BLOAD. BSAVE is the opposite of BLOAD. BSAVE has the speed of a hidden loader without the hassle. BSAVE saves ONLY lower 8K program image files for ONLY BLOAD to use.

Unlike CALL LOAD the BLOAD and BSAVE subprogram will work without CALL INIT being used first.

To save a program with hidden loaders just break program after loading is complete and type CALL BSAVE("DSK#.NAME") Remember to check for interrupts or the program will not work after loading with BLOAD. See ISRON and ISROFF.

NOTE: 8K of VDP memory MUST be free for BSAVE to function or a memory full error will result. Always place the BSAVE command at the top of the RXB program.

Programs

```

Initialize lower 8K.      | >100 CALL INIT
Load the assembly support. | >110 CALL LOAD("DSK1.MSETUP0")
Load the assembly support. | >120 CALL LOAD("DSK1.HDSR")
Turn on the mouse setup.  | >130 CALL LINK("MSETUP")
BSAVE the whole thing.    | >140 CALL BSAVE("DSK2.MOUSE")
                          |
Procedure for hidden loaders. |
Loads program on disk 1     | >CALL XBPGM("DSK1.LOAD")
Break program.              | PRESS FCTN 4 to break program.
Get address of interrupts.  | >CALL ISROFF(I)
See if they are on.        | >PRINT I
Save the program to disk.   | >CALL BSAVE("DSK2.EXAMPLE")
                          |

```

Options

AMS users will find this a easy way to save RXB AMS support.

EXAMPLE:

```
>100 CALL AMSINIT
>110 FOR L=0 TO 15 STEP 2
>120 CALL AMSBANK(L,L+1)
>130 CALL BSAVE("DSK1.BANK"&STR$(L/2))
>140 NEXT L
```

The above program would save RXB AMSBANK banks 0 to 15 into 8 program image files named BANK0 to BANK7 on disk 1.

See AMSINIT, AMSBANK, ISROFF, ISRON, EXECUTE, and MOVES.

Format BYE

CALL BYE

Description

The BYE command is the same as the BYE command in the EXTENDED BASIC MANUAL page 54. The BYE command ends the program and returns the system to a reset. BYE will close all open files before exiting to a reset.

Command

May only be used from command | >BYE mode.

Programs

May only be used in program | >100 CALL BYE mode. |

The INPUT asks for a Y to go | >110 INPUT "END PROGRAM":A\$ on, if not the loop forever. | >120 IF A\$<>"Y" THEN 110 Must be a Y so reset system. | >130 CALL BYE |

CALL BYE

CALL CLSALL

CALL CHAR(ALL,pattern-identifier[,...])

CALL CHARSET

CALL CHARSETALL

CALL COINC(#sprite,#sprite,tolerance,numeric-variable[,...])

CALL COLOR(ALL,foreground,background[,...])

CALL DISTANCE(#sprite,#sprite,numeric-variable[,...])

CALL FILES(number)

CALL GCHAR(row,column,numeric-variable[,...])

CALL HCHAR(row,column,character-code,repitition[,...])

CALL JOYST(key-unit,x-return,y-return[,...])

CALL KEY(key-unit,return-variable,status-variable[,...])

CALL KEY(string,key-unit,return-variable,status-variable[,...])

CALL MOTION(ALL,row-velocity,column-velocity[,...])

CALL NEW

CALL ONKEY(string,key-unit,return-variable,status-variable)

GOTO line-number[,...]

CALL SIZE

CALL VCHAR(row,column,character-code,repitition[,...])

CALL VERSION(numeric-variable)

CALL XBPGM(path-filename,file-number)

```

Format            CALL CAT("#"[,...])

                  CALL CAT("DSK#."[,...])

                  CALL CAT("DSK.DISKNAME."[,...])

                  CALL CAT(string-variable[,...])

                  CALL CAT(number[,...])

                  CALL CAT(numeric-variable[,...])

                  CALL CAT(ASC II value[,...])

```

Description

The CAT command catalogs the disk drive indicated by the # which can be 1 to z or by path name. The path name may be up to 30 characters long. A numeric variable or number can be used for drives 1 to 9 or if higher then it is assumed that the numeric-variable or number is a ASCII value between 30 to 255. This allows a catalog of a RAM-DISK designated by letters or control characters.

Also CAT can catalog up to 32 drives in one command.

The SPACE BAR will pause the catalog routine, then when the pressed again continues the catalog listing.

ANY OTHER KEY WILL ABORT THE CATALOG.

Programs

```

This line has pathname in A$ | >100 A$="DSK.ADISKNAME"
This line uses A$ for the name | >110 CALL CAT(A$)
of the device to catalog. |
This line will catalog drive 4 | >100 CALL CAT(N)
if N=4 |
This line will catalog drive C | >100 CALL CAT(X)
if X=67 (ASCII 67 is C) |
This line is path name. | >10 V$="WDS1.VOLUME.SUB-DIR."
This line will catalog device | >20 CALL CAT(V$)
WDS1 for directory VOLUME and |
catalog SUB-DIR |
This line catalogs drives 1 | >100 CALL CAT(1,2,3,"WDS1.")
then 2 then 3 then WDS1 |

```

Format CALL CHAR(character-code,pattern-identifier
[,...])

CALL CHAR(ALL,pattern-identifier[,...])

Description

See EXTENDED BASIC MANUAL page 56 for more data. Addition of the ALL command allows all the characters from 32 to 127 to be redefined all at once. Also CHAR now allows characters 30 (CURSOR) and 31 (EDGE CHARACTER) to be redefined or 144 to 156 may be redefined.

Programs

```

This line will define all the | >100 CALL CHAR(ALL,"")
characters as a empty string.|
FOR NEXT loop 30 to 127      | >110 FOR X=30 to 127
This line prints a character. | >120 PRINT CHR$(X);
NEXT to continue loop.      | >130 NEXT X
Reset characters 32 to 127    | >140 CALL CHARSETALL
This line repeats the program.| >150 GOTO 100
                             |
This line sets variable A$ up.| >100 A$="FF818181818181FF"
This line will define all the | >110 CALL CHAR(ALL,A$)
characters as a box.          |
                             |
This line defines the cursor. | >100 CALL CHAR(30,"FF81FF")
                             |
This line defines the edge    | >110 CALL CHAR(31,"55")
character.                    |

```

Options

Sprites may not be used if characters 144 to 156 are being redefined for use.

Format CALL CHARSETALL

Description

The CHARSETALL command is just like the CHARSET command, but it resets characters from 32 to 127 thus resetting characters 95 to 127 unlike CHARSET.

Exactly like CHARSET it also resets colors to original mode.

Programs

This resets all characters and
colors to original. | >100 CALL CHARSETALL
Set all characters the same. | >100 CALL CHAR(ALL,"4")
Set all colors the same. | >110 CALL COLOR(ALL,14,10)
Reset characters and colors | >120 CALL CHARSETALL
from character 32 to 127 |
Go start over. | >130 GOTO 100
 |

Format CALL CLSALL

Description

The CLSALL command will find and close all open files.
This allows programmers to save time and program space.

Programs

```
The program to the right will | >100 CALL CLSALL
CLOSE all open files.         |
                               |
This opens the printer.       | >100 OPEN #9:"PIO",OUTPUT
This opens a disk file JUNK.  | >110 OPEN #2:"DSK1.JUNK",INPUT
This opens a RS232 port.      | >120 OPEN #4:"RS232",OUTPUT
This opens a disk file CRAP.  | >130 OPEN #7:"DSK2.CRAP",OUTPUT
This closes all files.        | >140 CALL CLSALL
                               |
```

Format CALL COINC(#sprite-number,#sprite-number,
 tolerance,numeric-variable[,...])

 CALL COINC(#sprite-number,dot-row,dot-column,
 tolerance,numeric-variable[,...])

 CALL COINC(ALL,numeric-variable[,...])

Description

See EXTENDED BASIC MANUAL PAGE 64 for more data. The only difference is the use the comma has been added for auto-repeat. Previously a COINC only allowed one sprite comparison per program line.

Programs

* See EXTENDED BASIC MANUAL page 64

```

Clear screen set and X to 190 | >100 CALL CLEAR :: X=190
                               |
Set up 3 sprites to be on    | >110 CALL SPRITE(#1,65,2,9,X,
the same vertical plane.    | 20,0,#2,66,2,9,X,30,0,#3,67,
                               | 2,9,X,-20,0)
                               |
COINC scans ALL sprites for a | >120 CALL COINC(ALL,A,#1,#2,1
collision then #1,#2,#3 also. | 2,B,#1,#3,12,C,#2,#3,12,D)
                               |
Print results on screen.     | >130 PRINT A;B;C;D
Loop forever to line 120     | >140 GOTO 120
                               |

```

The above program in RXB will put a -1 in A,B,C,D variables unlike normal XB that would never detect all 4 collisions.

Options

While characters 144 to 159 are being used, you cannot use sprites. Notice the ALL option MUST ALWAYS BE FIRST as it was given highest priority to increase the detection rate. Though the ALL option does not improve much, the normal COINC detections are slightly faster as the interpreter is not looking to find the next COINC command on the next line number. Instead the comma and the next sprite is checked.

Format	CALL COLOR(#sprite-number,foreground-color[,...])
	CALL COLOR(character-set,foreground-color, background-color[,...])
	CALL COLOR(ALL,foreground-color,background-color [,...])

Description

See EXTENDED BASIC MANUAL page 66, presently modifications to the COLOR subprogram is ALL will change character sets 0 to 14 to the same foreground and background colors.

SET NUMBER	CHARACTER CODES
0	30-31
1	32-39
2	40-47
3	48-55
4	56-63
5	64-71
6	72-79
7	80-87
8	88-95
9	96-103
10	104-111
11	112-119
12	120-127
13	128-135
14	136-143
15	144-151 (RXB addition)
16	152-159 (RXB addition)

Programs

```

All characters set foreground | >100 CALL COLOR(ALL,2,11)
2 and background 11         |
All characters set foreground| >100 CALL COLOR(ALL,1,2,ALL,2
transparent and background 1 | 1) :: GOTO 100
                             |

```

Options

While characters 144 to 159 are being used, you cannot use sprites. Sets 0 to 16 may be individually set.

Format COPY start line-end line,new start line,increment

Description

The COPY command is used to copy a program line or block of program lines to any other location in the program. The COPY does not affect the original lines and leaves them intact.

The block to be copied is defined by start line and end line. If either of these numbers are omitted, the defaults are the first program line and the last program line. However, at least one number and a dash must be entered (both can't be omitted), and there must be at least one valid program line between start line and end line. To copy one line enter it as both the start line and end line number. If any of the above conditions are not met, a Bad Line Number Error will result.

The new start line number defines the new line number of the first line in the block to be copied. This number must be entered. There is no default. The increment defines the line number spacing of the copied lines and may be omitted. The default is 10. There must be sufficient space in the program for the copied segment to fit between new start line number and the next program line following the location where the block will be moved. If not, a Bad Line Number Error message is reported. This problem can be corrected by using a smaller increment, or by using RES to open up space for the segment. A Bad Line Number Error also results if the copying process would result in a line number higher than 32767.

The COPY routine does not change any program references to the copied lines. It is an exact copy of the source lines with new line numbers. A check for sufficient memory space is made before each line is copied. If space is not available the copying process is halted and a Memory Full Error is reported.

Before the first line is copied, any open files are closed and all variables are lost.

Description Addendum PLEASE NOTE:

The COPY command copies the lines in reverse order
If the copying process is halted due to insufficient
memory space, any unoccupied lines will be at the
beginning of the block.

Commands

Lines 100 to 150 are copied to | >COPY 100-150,9000,5
line 9000 and incremented by 5 |

Line 10 is copied to line 25 | >COPY 10-10,25
|

Line 5 to last line are copied | >COPY 5-,99
to 99 and incremented by 10 |
(Default). |

Format CALL CUTDIR(pathname,directory-name[,...])

 CALL CUTDIR(string-varialbe,string-variable
 [,...])

Description

The CUTDIR subprogram removes directories and subdirectories on hard drives. The pathname determines the device used and the pathname can be up to 255 characters in length. The pathname must end with a period and the directory may only be 10 characters in length. Only a SCSI controller supports this command. CUTDIR will remove a directory and all its sub-directories at once. BE CAREFUL WITH THIS COMMAND!

Programs

This line removes a directory | >CALL CUTDIR("WDS1.", "TEST")
named TEST on hard drive 1. |
|
This line removes directory | >100 CALL CUTDIR("WDS1.", "ONE
ONE and all sub-directories | ")
that are within it. |
|
This line would remove every | >100 CALL CUTDIR("WDS1.", "WOW
thing off WDS1 if WOW had | ")
all main directories in it. |

Options

This command requires a updated SCSI EPROM. The original SCSI EPROM did not include CUT DIRECTORY SUPPORT.

Format DEL start line-end line

Description

The DEL command is used to delete a line or block of lines from a program. Start line number and end line number define the lines to be deleted. If start line number is omitted, line deletion will begin at the first line of the program. In this case, end line number must be preceded by a dash. If end line number is omitted, line deletion will end at the last line of the program. If start line number and end line number are omitted, then the first line number of the program to the last line number of the program is deleted. At least one valid program line must exist between start line number and end line number or a Bad Line Number Error will be reported. If only one line number is given without a dash, then that one line will be deleted.

After the DEL command has executed any open files are closed and all variables are lost.

Commands

Lines 100 to 150 are deleted.	>DEL 100-150
Line 10 is deleted.	>DEL 10
Line 5 to last line are deleted.	>DEL 5-
First line to 80 are deleted.	>DEL -80

Format

```
CALL DIR("#"[,...])  
  
CALL DIR("DSK#."[,...])  
  
CALL DIR("DSK.DISKNAME."[,...])  
  
CALL DIR(string-variable[,...])  
  
CALL DIR(number[,...])  
  
CALL DIR(numeric-variable[,...])  
  
CALL DIR(ASC II value[,...])
```

Description

The DIR command catalogs the disk drive indicated by the # which can be 1 to z or by path name. The path name may be up to 30 characters long. A numeric variable or number can be used for drives 1 to 9 or if higher then it is assumed that the numeric-variable or number is a ASCII value between 30 to 255. This allows a catalog of a RAM-DISK designated by letters or control characters.

RXB DIR can be used from program mode or command mode. Also DIR can catalog up to 32 drives in one command.

The SPACE BAR will pause the catalog routine, then when the pressed again continues the catalog listing.

ANY OTHER KEY WILL ABORT THE CATALOG. See CAT for more info.

Programs

```
This line puts the pathname in | >100 A$="DSK.ADISKNAME"
the string A$ |
This line uses A$ for the name | >110 CALL DIR(A$)
of the device to catalog. |
|
This line will catalog drive 4 | >100 CALL DIR(N)
if N=4 |
|
This line will catalog drive C | >100 CALL DIR(X)
if X=67 (ASCII 67 is C) |
|
This line is path name. | >10 V$="WDS1.VOLUME.SUB-DIR."
This line will catalog device | >20 CALL DIR(V$)
WDS1 for directory VOLUME and |
catalog SUB-DIR |
|
This line catalogs drives 1 | >100 CALL DIR(1,2,3,"WDS1.")
then 2 then 3 then WDS1 |
```

```
CALL DISTANCE(#sprite-number,dot-row,  
dot-column,numeric-variable[,...])
```

Description

The only thing added by RXB to DISTANCE is the auto repeat.
See EXTENDED BASIC MANUAL page 80 for more data.

Program

```
The program at the right will | >100 CALL CLEAR
set up 3 sprites on screen and | >110 CALL SPRITE(#1,65,7,99,9
start them moving.           | 9,0,10,#2,66,4,99,99,10,0,#3
                               | ,67,2,1,2,-50,-50)
Scans three sprites locations | >120 CALL DISTANCE(#1,#2,D,#1
and returns the distance from | #3,E,#2,#3,F)
each other squared.           | >130 DISPLAY AT(1,1):"#1/#2";
                               | D:"#1/#3";E:"#2/#3";F)
Restart loop                   | >140 GOTO 120
```

Options

While characters 144 to 159 are being used, you cannot use sprites. The DISTANCE subprogram does get more accurate if you have more than one to check at a time, but is slightly faster than normal XB as DISTANCE in RXB does not require a search for another line number to CALL DISTANCE and find a value. The RXB version just goes to the comma and finds the next value of DISTANCE, so is much faster and saves program memory.

Format CALL DUPCHAR(character-code,character-code
 [,...])

Description

The DUPCHAR subprogram allows you to duplicate character definitions. You can duplicate character-codes from 30 to 159. The first character-code specifies the character-code to be duplicated, and the second character-code specifies the destination character-code. By duplicating a character definition using sprites would result in duplicate sprites.

Program

The program at the right will | >100 CALL DUPCHAR(65,66)
duplicate the character |
definition of character-code |
65 into character definition |
of character-code 66. |
The program at the right will | >100 FOR C=32 TO 158
blank out all character-code | >110 PRINT CHR\$(C);
definitions from 33 to 159. | >120 CALL DUPCHAR(C,C+1)
Line 110 is just to show what | >130 NEXT C
the character was before the |
DUPCHAR subprogram blanked it.|

Format	CALL DUPCOLOR(character-set,character-set [,...])
	CALL DUPCOLOR(#sprite-number,#sprite-number, [,...])

Description

The DUPCOLOR subprogram duplicates foreground and background colors of the first set into the second set. Or the first sprite-number color into the second sprite-number color. The character-set numbers are given below:

set-number	character-codes
0	30 to 31
1	32 to 39
2	40 to 47
3	48 to 55
4	56 to 63
5	64 to 71
6	72 to 79
7	80 to 87
8	88 to 95
9	96 to 103
10	104 to 111
11	112 to 119
12	120 to 127
13	128 to 135
14	136 to 143
(also sprite table) 15	144 to 151
(also sprite table) 16	152 to 159

Programs

```
Duplicates color set 6 in      | >100 CALL DUPCOLOR(6,9)
color set 9                  |
Clear screen                 | >100 CALL CLEAR
Line 110 sets up two sprites | >110 CALL SPRITE(#1,65,2,99,9
on screen.                   | 9,#2,66,16,88,88)
Delay loop.                  | >120 FOR X=1 TO IE3 :: NEXT X
Duplicate sprite-number 1    | >130 CALL DUPCOLOR(#1,#2) ::
into sprite-number 2 and loop | GOTO 140
```


Format	RUN "EA"	
	DELETE "EA"	
	CALL XBPGM("EA")	
	CALL CAT("EA")	
	OLD EA	
	SAVE "EA"	-(Must have a program within - memory to work at all)
	CALL EA	

Description

The EA DSR (Device Service Routine) allows access to the Editor Assembler section of RXB. The access will work only if the DSR is the GPLDSR or LINK DSR. In other words, a DSR that acknowledges any type of DSR in RAM, ROM, GROM, GRAM, or VDP. Most DSR's only accept DSK or PIO. Others like the SAVE or LIST commands will only work with a program in the memory first. Still others like CALL LOAD("EA") must have the CALL INIT command used first. Almost all DSR's today only acknowledge the ROM or RAM DSR's.

Programs

Go to the Editor Assembler.	>100 CALL XBPGM("EA")
This line asks for a string.	>100 INPUT A\$:: DELETE A\$
Type EA will go to EA module	
Switch to Editor Assembler	>CALL CAT("EA")
Lower case can also be used.	>call ea
Strange looping effect.	>CALL EAPGM("EA")

Options

BASIC and XB are also available.

Format CALL EALR("access-name")

Description

The EALR subprogram is used to switch to the Editor Assembler Load and Run menu screen prompt. EALR will only load and run Editor Assembler DISPLAY FIXED OBJECT FILES created by the Editor Assembler for the Editor Assembler environment, not the EXTENDED BASIC DISPLAY FIXED OBJECT FILES. They've never been compatible, hence one of RXB's reasons for existing. The access-name is moved into the Editor Assembler and the name is loaded onto the screen so you can see it. This gives you a chance to change the disk if needed, or to see what is wrong if it does not load. After the DISPLAY FIXED OBJECT FILE is loaded, you will receive the normal 'Program Name?' prompt. This name would be the same as the link name from Editor Assembler BASIC. You can ABORT the loader by holding the FCTN BACK (9) key while the name is being placed onto the screen. If an error occurs the code will be returned onto screen and you must press ENTER to restart the loader.

Description Addendum

EALR only works from EXTENDED BASIC, not BASIC.

Programs

The program at the right will | >100 CALL EALR("DSK3.SAVE")
load a Display/Fixed 80 file |
named SAVE from disk drive 3. |
|

This program loads a Display/ | >100 CALL EALR("DSK.DNAME.FNA
Fixed Object file named FNAME | ME")
after searching all disk |
drives and RAMDISKS for the |
disk named DNAME. |
|

Format CALL EAPGM("access-name")

Description

The EAPGM subprogram is used to switch to the Editor Assembler 'Run Program file?' screen prompt. It will not run EXTENDED XB programs or BASIC programs for that see XBPGM.

The access-name is moved into the Editor Assembler and the name is loaded onto screen so you can see it. This gives you a chance to change the disk if needed, or to see what is wrong if it does not load. After the Program Image file is loaded, it executes the program normally.

You can ABORT the loader by holding down the FCTN BACK (9) key while the name is being placed onto the screen. If an error occurs the error code will be returned onto the screen and you must press ENTER to restart the loader.

Description Addendum

EAPGM only works from EXTENDED BASIC, not BASIC.

Programs

The program at the right will | >100 CALL EAPGM("DSK2.FW")
load a Program Image file |
named FW from disk drive 2. |

This program loads a Program | >100 CALL EAPGM("DSK.FW.MG")
Image file named MG after |
searching all disk drives and |
and RAMDISKS for a disk named |
FW. |

This program causes a search | >100 T\$="SCS1.ART.MAXPRO"
for MAXPRO in directory ART | >110 CALL EAPGM(T\$)
on SCS1. |

Format CALL EXECUTE(cpu-address[,...])

 CALL EXECUTE(numeric-variable[,...])

Description

The EXECUTE subprogram directly goes to the cpu-address and expects to find 4 bytes to be present. The bytes are 1 and 2 define the workspace register address. Bytes 3 and 4 define the address to start execution at in cpu memory. Programmers can see this is a BLWP at a cpu-address. The programmer is responsible for keeping track of the workspace and program space he is using. Also for any registers while doing a BL or another context switch. A RTWP will end either a BL or a BLWP as long as registers set are not changed. By using CALL LOAD or CALL MOVES the programmer can set up a BLWP routine in the lower 8K by filling the registers with values first, then using CALL EXECUTE to directly complete these commands. This is faster then CALL LINK as no interpretation of the access or values are checked.

EXECUTE runs a XML link from GPL by moving 12 bytes from the Fast RAM at HEX 8300 to VDP at HEX 03C0 then moving the value in FAC passed from XB to HEX 8304 and does a GPL XML >F0 After a RTWP by the Assembly program, it returns VDP HEX 03C0 to Fast RAM HEX 8300 so the 12 bytes are restored. Thus this allows programmers use of FAC and ARG areas in Fast RAM.

Here is the program loaded into Fast RAM by EXECUTE:

	AORG	>8300	
CPUPGM	DATA	>8302	First address.
	BLWP	@>834A	Switch context
			with FAC as dummy.
	CLR	@>837C	Clear for GPL return.
	RT		Return to GPL.
	END		

If a programmer absolutely must use Fast RAM for his program I suggest he set up a buffer for saving HEX 8300 to HEX 83FF if only so it will not mess up any GPL pointers and don't go and mess up the 12 bytes at VDP HEX >03C0. Then the only thing to worry about is messing up something else.

Programs

```

Line 100 initializes lower 8k | >100 CALL INIT
Line 110 loads the assembly | >110 CALL LOAD(9838,47,0,38,1
program shown below. VMBR | 14,4,32,32,44,3,128)
Line 120 loads registers with | >120 CALL LOAD(12032,0,0,48,0
VDP address, Buffer, Length. | ,2,255)
Line 130 runs line 110 program | >130 CALL EXECUTE(9838)
Line 140 loads the assembly | >140 CALL LOAD(9838,47,0,38,1
program shown below. VMBW | 14,4,32,32,36,3,128)
Line 150 loads registers with | >150 CALL LOAD(12032,0,0,48,0
VDP address, Buffer, Length. | ,2,255)
Line 160 runs line 140 program | >160 CALL EXECUTE(9838)
Line 170 put a command in here | >170 CALL VCHAR(1,1,32,768)
Line 180 loops to line 160 | >180 GOTO 160

```

HEX ADDRESS | HEX VALUE | ASSEMBLY COMMAND EQUIVALENT

```

>266E      >2F00      DATA >2F00 (workspace area address)
>2670      >2672      DATA >2672 (start execution address)
>2672      >0420      BLWP (first executed command)
>2674      >202C      @VMBR (or >2024 VMBW)
>2676      >0380      RTWP

```

```

>2F00      >0000      REGISTER 0 (VDP address)
>2F02      >3000      REGISTER 1 (RAM buffer address)
>2F04      >02FF      REGISTER 2 (length of text)

```

Normal XB using LINK.

```

Initialize for Assembly. | >100 CALL INIT
Load support routine. | >110 CALL LOAD("DSK1.TEST")
LINK to program. | >120 CALL LINK("GO")
RXB EXECUTE EXAMPLE. |
Initialize for Assembly. | >100 CALL INIT
Load support routine. | >110 CALL LOAD("DSK1.TEST")
EXECUTE program address. | >120 CALL EXECUTE(13842)

```

EXECUTE does no checking so the address must be correct.
The LINK method finds the name and uses the 2 byte address
after the name to run the Assembly. EXECUTE just runs the
address without looking for a name thus faster.

Options.

Dependent on Programmers use and skill.

Format CALL FCOPY(master-pathname,filename,
 copy-pathname,filename[,...])

 CALL FCOPY(string-variable,string-variable,
 string-variable,string-variable[,...])

 CALL FCOPY(number,filename,number,filename
 [,...])

Description

The FCOPY subprogram copies files from drive to drive. The pathname determines the device used and the pathname can be up to 255 characters in length. The Myarc HFDC can only support 29 character pathnames plus the filename of 10, so that would add up to 39 characters total. The pathname must end with a period and the filename may only be 10 characters in length. FCOPY can copy up to 12 files from 12 drives to 12 drives and 12 different filenames all in one command.

NOTE:

FCOPY does have a cost for existing in the TI, and the price is 4K of VDP must be available for use. A *STACK OVERFLOW* or *MEMORY FULL* error will result if not enough VDP memory is available. Using FCOPY leaves 8K available for programs. USE RUN TO RESET MEMORY FOR FEWER CRASHES!

Programs

Copies file TESTER from drive 1 to drive 2 named JUNKER.		>CALL FCOPY(1,"TESTER",2,"JUNKER")
Copies file FW from DSK.FWB. to DSK.FWB. named UTIL1		>CALL FCOPY("DSK.FWB.", "FW", "DSK.FWB.", "UTIL1")

This next program will copy any directory to any directory.
Or any disk to any disk, all the files on the disk.

```
|
Name of program.      | >100 ! COPY DIR TO DIR
Clear the screen.     | >110 CALL CLEAR
Get master path of device. | >120 INPUT "MASTER PATH:":M$
Get copy path of device. | >130 INPUT "COPY  PATH:":C$
Open a Catalog of device. | >140 OPEN #1:M$,INTERNAL,INPU
                        | >T,FIXED 38
Get a filename.       | >150 INPUT #1:A$,B,C,D
If first name, ignore diskname | >160 X=X+1 :: IF X=1 THEN 150
If filename empty end program, | >170 IF LEN(A$)=0 THEN CALL
close files and restart.      | >CLSALL :: RUN
Count files and show pathname. | >180 PRINT X-1: :C$&A$
Copy files.              | >190 CALL FCOPY(M$,A$,C$,A$)
Continue endlessly.      | >200 GOTO 150
|
```

Format CALL FILES(number)

 CALL FILES(numeric-variable)

Description

The FILES subprogram differs from the Disk Controller FILES on the CorComp, TI, Myarc or Parcom versions. All of these require a NEW after CALL FILES. NEW is executed after the FILES subprogram in RXB, so there is no need to use NEW. Also RXB FILES accepts values from 1 to 15 unlike the other FILES routines that can only accept 1 to 9. Each open file reduces VDP by 534 bytes, plus each file opened will use 518 bytes more.

Programs

FILES opens usual buffers.	>CALL FILES(3)
FILES ends the program and	>100 CALL FILES(1)
executes NEW.	
Only possible in RXB	>100 CALL FILES(15)
	>NEW
	>SIZE

Will display 5624 Bytes of Stack free and 24488 Bytes of Program space free. At this point up to 15 files may be open at the same time. Not recommended but possible now.

Options

See XBPGM for even more powerful applications made easy. For example CALL XBPGM("DSK1.LOAD",2) will CALL FILES(2) then NEW then RUN "DSK1.LOAD"

Format CALL GCHAR(row,column,numeric-variable[,...])

Description

See EXTENDED BASIC MANUAL page 88 for more data. The only change to GCHAR is the auto-repeat function.

Programs

```
This line stores the character| >100 CALL GCHAR(4,5,A,4,6,B)
at row 4 column 5 in A, then |
stores character at row 4    |
column 6 in B.               |
Gets row 9 column 3 in Q and | >100 CALL GCHAR(9,3,Q,9,4,R)
row 9 column 4 in R.         |
Put R at row 9 column 3 and  | >110 CALL HCHAR(9,3,R,1,9,4,Q
Q at row 9 column 4          | ,1)
Continue loop.               | >120 GOTO 100
```

Options

CALL GCHAR in RXB is much faster than normal XB now.

Format CALL GMOTION(#sprite-number,row-velocity,
 column-velocity[,...])

Description

The GMOTION subprogram returns the row-velocity and column-velocity as numbers from -128 to 127. If the sprite is not defined, row-velocity and column-velocity is set to zero. The sprite continues to move after its motion is returned, so this must be allowed for. See EXTENDED BASIC MANUAL MOTION subprogram for more data.

Program

GMOTION returns the row-velocity into X and the column-velocity into Y.	>100 CALL GMOTION(#1,X,Y)
Set up screen and up,down, left, right variables A(0) and A(1)	>100 A(0)=-1::A(1)=1::CALL CL
	EAR::CALL MAGNIFY(2)::CALL S
	CREEN(15)
Loop for 28 sprites.	>110 FOR S=1 TO 28
Set up 28 random sprites with random colors and motion.	>120 CALL SPRITE(#S,64+S,INT(RND*16)+1,20+S,50+S,INT(A(RND*1))*INT(RND*127),INT(A(RND*1))*INT(RND*127))
Loop counter.	>130 NEXT S
Random sprite selector, get that sprites motion, put the values on screen.	>140 S=INT(RND*28)+1::CALL GMOTION(#S,X,Y)::CALL HPUT(24,3,"CALL GMOTION("#&STR\$(S)&" ,&STR\$(X)&" ,&STR\$(Y)&")")
Delay loop.	>150 FOR L=1 TO 1E3::NEXT L
Clear screen and Z+1.	>160 CALL CLEAR::Z=Z+1::IF
Loop till Z>8	Z<8 THEN 140

Options

While characters 144 to 159 are being used, you cannot use sprites.

Format CALL HCHAR(row,column,character-code)

 CALL HCHAR(row,column,character-code,
 repetition[,...])

Description

See EXTENDED BASIC MANUAL page 92 for more data. The only change to HCHAR is the auto-repeat function. Notice the new auto-repeat must have the repetitions used or it gets row confused with repetitions.

Programs

This line puts character 38 at | >100 CALL HCHAR(1,1,38,99,9,1
row 1 column 1 99 times, then | ,87)
puts character code 87 at |
row 9 column 1 |
|
Fills screen with characters. | >100 CALL HCHAR(1,1,32,768,1,
| 1,65,768,1,1,97,768,1,1,30,7
| 68) :: GOTO 100
|

Options

CALL HCHAR in RXB is faster than normal XB as separate line numbers are needed to continue placing characters on screen.

```
Format      CALL HEX(string-variable,numeric-variable[,...
           ])

           CALL HEX(numeric-variable,string-variable[,...
           ])
```

Description

The HEX subprogram converts Decimal to Hexadecimal or from Hexadecimal to Decimal. If a number or numeric-variable is first, HEX will convert the Decimal floating point value (Rounded off) to a four character sting and puts the string into the string-variable. If a string or string-variable is first, HEX will convert the String into a Decimal integer and put it into the numeric-variable. A numeric-variable or number ranges from -32768 to 32767 or the Hexadecimal equivalent of >8000 to >7FFF. The > is not used in HEX.

When a string or string-variable is null (length of zero) the numeric-variable will contain 0. The opposite is if a number or numeric-variable is 0 then the string-variable will contain a length of four and a value of >0000. Any time a string-variable is second it will be cleared before being assigned a new string value. All strings in HEX must be right justified or are returned as right justified, thus each string will be padded with zeros.

HEX will only use the first four characters of a string to convert the value, it will ignore the rest of the string.

Errors will result if a string contains characters other than 0-9 and A-F or a-f. Errors will result if a number is less than -32768 or larger than 32767.

CALL HEX can be used for RXB CALL SECTOR but requires that two strings be combined for Hard Drive access. A CALL HEX of -1 equals >FFFF and -32768 equals >8000 thus 1 equals >0001 and 32767 equals >7FFF so:

FOR SECTOR=0 to 32767 would be 0 to >7FFF

FOR SECTOR=-32768 to -1 would be >8000 to >FFFF

Only good for a 65535 sector hard drive.

As SECTOR was intended for Hard Drive access using a normal DEC to HEX routine a preferred method over RXB

CALL HEX simply for ease of use is required. (SORRY)
>FFFFFFFF would require a 4294967295 sector hard drive.

CALL HEX is designed for memory access not hard drives.
(again sorry but this was intended)

Programs

```

From command mode.      |
Upper case              | >CALL HEX("F",V)
or lower case           | >CALL HEX("f",V)
will both return same result. | >PRINT V
V=15                    |
                        |
Line 100 sets address counter. | >100 FOR D=-32768 TO 32767
Line 110 converts it to HEX. | >110 CALL HEX(D,H$)
Line 120 shows DEC to HEX. | >120 PRINT D,H$
Line 130 continues loop count. | >130 NEXT D
                        |
Line 100 asks for HEX number. | >100 INPUT "HEX=":H$
Line 110 converts HEX to DEC. | >110 CALL HEX(H$,D)
Line 120 shows DEC equivalent. | >120 PRINT D: :
Line 130 starts program over. | >130 GOTO 100
                        |
Line 100 list of numbers. | >100 DATA 200,124,97,249,140,
It takes 8 bytes to store any | 77,81,173,254,78,93,12,38,65
number in XB.             | ,55,6,0
Line 110 read list into N. | >110 READ N
Line 120 convert to HEX. | >120 CALL HEX(N,N$)
Line 130 Save into a string as | >130 S$=S$&SEG$(N$,2,2)
it takes 4 bytes per number. |
Line 140 check for end of list | >140 IF N<>0 THEN 110
Line 150 show number of bytes | >150 PRINT "NORMAL:";8*16
used to store numbers.      |
Line 160 show number of bytes | >160 PRINT "USED: ";LEN(S$)+
it would have used.         | 1
Line 170 show number of bytes | >170 PRINT "SAVED ";(8*16)-(
it saved using string instead. | LEN(S$)+1);"BYTES"
                        |

```

Format CALL HGET(row,column,length,string-variable
 [,...])

Description

The HGET subprogram returns into a string-variable from the screen at row and column. Length determines how many characters to put into the string-variable. Row numbers from 1 to 24 and column numbers from 1 to 32. Length may number from 1 to 255. If HGET comes to the edge of the screen then it wraps to the other side.

Programs

The program to the right will | >100 CALL HGET(5,9,11,E\$)
put into string-variable E\$ |
the 11 characters at row 5 and |
column 9. |

| >100 CALL HGET(1,3,5,M\$,9,3,1
The program to the right will | ,Q\$,24,1,32,N\$)
put into string-variable M\$ |
the 5 characters at row 1 and |
column 3, then put into |
string-variable Q\$ the 1 |
character at row 9 and column |
3, then put into |
string-variable N\$ the 32 |
characters at row 24 and |
column 1.

Format CALL HONK

Description

The HONK command produces the same sound as the ACCEPT or in INPUT or if a error occurs.

Programs

```
The program to the right will | >100 PRINT "YN ?"
will produce a honk sound.    |
Key request for YN.           | >110 CALL KEY("YN",0,K,S)
Indicate N was pressed.       | >120 IF K=78 THEN CALL HONK
Continue on with program.     | >130 GOTO 100
                               |
```

Format

```
CALL HPUT(row,column,string[,...])

CALL HPUT(row,column,string-variable[,...])

CALL HPUT(row,column,number[,...])

CALL HPUT(row,column,numeric-variable[,...])
```

Description

The HPUT subprogram puts a string, string-variable, number, or numeric-variable onto the screen at row and column. The row numbers from 1 to 24 and column numbers for 1 to 32. If the string, string-variable, number, or numeric-variable being put onto screen goes to an edge it wraps to the other side. Unlike the EXTENDED BASIC DISPLAY AT the HPUT subprogram will not scroll the screen.

Programs

```
Line 100 puts string "THIS" onl >100 CALL HPUT(10,4,"THIS")
the screen at row 10 and      |
column 4.                    |
                             |
Line 110 sets string-variable | >110 A$="HPUT"
A$ equal to string "HPUT"    |
                             |
Line 120 puts string "is" at | >120 CALL HPUT(12,5,"is",14,4
row 12 and column 5, then puts| ,A$)
string-variable A$ at row 14 |
and column 4.                |
                             |
Line 100 puts string A$ at row| >100 CALL HPUT(16,5,A$)
16 and column 5.             |
                             |
Puts 456 at row 10 col 15    | >100 CALL HPUT(10,15,456)
                             |
```

Format CALL INIT

Description

The INIT command is the same as the EXTENDED BASIC MANUAL page 101. Originally INIT loaded more data than actually existed, this has been fixed. The other correction is that you no longer have to use INIT before LINK, or LOAD. They will function if INIT has been called first or not. Unless loading a program that needs the INIT.

Programs

The program to the right will | >100 CALL INIT
initialize the lower 8K by |
loading support routines for |
assembly. |
|

Format CALL INVERSE(character-code[,...])

 CALL INVERSE(ALL[,...])

Description

The INVERSE subprogram finds the character definition of the character-code and inverts all the bytes in the character definition. That means it just reverses the foreground and background. The ALL feature inverts characters 30 to 143 thus not affecting characters 144 to 159 as this would destroy sprites.

Programs

The program to the right will | >100 CALL INVERSE(65)
 INVERSE all character-code (A)|
 in the character definition |
 table in memory. |

The program to the right will | >100 CALL INVERSE(ALL)
 INVERSE all character-codes |
 from 30 to 143. |

Line 100 will ask for a string | >100 INPUT A\$
 of characters terminated by |
 the ENTER key. |

Line 110 is a loop to counter. | >110 FOR L=1 TO LEN(A\$)
 Line 120 singles each one of | >120 C=ASC(SEG\$(A\$,L,1))
 the characters in A\$. |

Line 130 INVERSEs each one. | >130 CALL INVERSE(C)
 Line 140 completes the loop. | >140 NEXT L
 Line 150 restarts the program. | >150 GOTO 100
 (Be sure and not enter any blank characters in this program)

Format CALL I0(type,address[,...])

 CALL I0(type,bits,cru-base,variable,variable
 [,...])

 CALL I0(type,length,vdp-address[,...])

Description

The I0 subprogram allows access to and control of any chip in the console or peripheral cards. The type refers to different access methods like playing sound from GROM or VDP memory automatically. The type can also specify reading or writing directly to a Control Register Unit (CRU) address. Thereby allowing direct chip control, or direct chip bypass if the user wishes. The I0 subprogram is a Graphics Programming Language (GPL) command. So the function is exactly like GPL despite being run from the XB environment. As most of XB is written in GPL the user gains greater GPL like control. After all the Operating System is written in GPL for a good reason.*Note these docs are from GPL Manuals.

type	address specifications
~~~~~	~~~~~
0 -----	GROM sound list address.
1 -----	VDP sound list address.
2 -----	CRU input.
3 -----	CRU output.
4 -----	VDP address of Cassette write list.
5 -----	VDP address of Cassette read list.
6 -----	VDP address of Cassette verify list.

The length specifies the number of bytes. The length can be from -32768 to 32767 depending on the amount of VDP memory that is available. Of course a value of -32768 is HEX >8000 and 32767 is HEX >7FFF and VDP normally in a TI is only 16384 or HEX >4000 of VDP. So be careful or lock-up will result. The cru-base is the CRU address divided by 2 in decimal form as the command automatically doubles the value input. The CRU -base ranges from 0 to 8191 or HEX >0000 to >1FFF with a EVEN address for 8 bits or more being scanned. That means that a value of 8191 will lock-up the system as it is looking for a bit in 8192 that does not exist.

-----  
The variable can input or output values ranging from 0 to 255 as that is equivalent to a single byte value. As there are two variables 16 bits can be represented in the two 8 bit variables. If CRU input reads less than 8 bits, the unused bits in the byte are reset to zero. If CRU input reads less than 16 but more than 8 bits, the unused bits in the word will be reset to zero. The bits range from 1 to 16 for input or output.

#### AUTO-SOUND INSTRUCTION GROM/GRAM/VDP

Format           CALL IO(type,address[,...])

Control of the Sound Generator Chip (SGC) in the system console is through a pre-defined table in GROM/GRAM or VDP memory. Sound output is controlled by the table and the VDP Interrupt Service Routine (ISR). A control byte at the end of the table can cause control to loop back up in the table to continue, or end sound output. The format of the table is the same regardless of where it resides. The table consists of a series of blocks, each of which contains a series of bytes which are directly output to the SGC.

Since the VDP generates 60 interrupts per second, the interrupt count is expressed in units of one-sixtieth of a second.

When the IO command is called, upon the next occurring VDP interrupt, the first block of bytes is output to the SGC. The interpreter (Operating System) waits the requested number of interrupts (for example, if interrupt counts are 1, every interrupt causes the next block to be output). Remember that interpretation of XB continues normally while the SGC control is enabled.

The sound control can be terminated by using an interrupt count of 0 in the last block of the table. Alternatively, a primitive looping control is provided by using a block whose first byte is 0, and the next 2 bytes indicate an address in the same memory space of the next sound block to use. (That means one block points to another block only in the same type of memory).

---

If the first byte is hex FF or decimal 255, the next two bytes indicate an address in the other memory space. (That means one block points to another block but in another type of memory.) These allow switching sound lists from GROM/GRAM to VDP or VDP to GRAM/GROM. By making this the beginning of the entire table, the sound sequence can be made to repeat indefinitely.

The type 0 indicates sound lists in GROM or GRAM and type 1 indicates sound lists in VDP.

Executing a sound list while table-driven sound control is already in progress (from a previous sound list) causes the old sound control to be totally supplanted by the new sound instruction. (That means any sound chip command will override old sound chip commands).

The SGC has 3 tone (square wave) generators - 0, 1, and 2 all of which can be working simultaneously or in combination. The frequency (pitch) and attenuation (volume) of each generator can be independently controlled. In addition, there is a noise generator which can output white or periodic noise. For more information on controlling the SGC, see the TSM9919 SGC specification.

ATTENUATION CONTROL (for generators 0, 1, 2 or 3)

One byte must be transmitted to the SGC:

Binary      1-REG#-1-Attenuation

REG# = register number (0,1,2,3)

Attenuation = Attenuation/2

(e.g. A=0000 0 db = highest volume;  
A=1000 16 db = medium volume;  
A=1111 30 db = off. )

EXAMPLE: 1 10 1 0000 : turn on gen. #2 highest volume.  
          1 01 1 0100 : turn on gen. #1 medium high volume.  
          1 11 1 1111 | turn off gen. #3 (noise generator).

# FREQUENCY CONTROL (for generators 0, 1, 2)

Two bytes must be transmitted to the SGC for a given register and to compute the number of counts from the frequency F  
 use:  $N = 111860 / F$

Binary 1-REG#-N(1s 4 bits)-00-N(ms 6 bits)  
 Note that N must be split up into its least significant 4 bits and most significant 6 bits (10 bits total).

The lowest frequency possible is 110 Hz and the highest is 55938 Hz.

# NOISE CONTROL

One byte must be transmitted to the SGC:

Binary 1-1-1-0-0-T-S

T = 0 for white noise, 1 for periodic noise;  
 S = Shift rate (0,1,2,3) = frequency center of noise.  
 S=3=frequency dependent on the frequency of tone generator #3.

---

 Programs

```

Line 100 clears screen.      | >100 CALL CLEAR ! Chimes
Line 110 to ...              | >110 DATA 5,159,191,223,255,2
                              | 27,1,9,142,1,164,2,197,1,144
                              | ,182,211,6,3,145,183,212,5,3
                              | ,146,184,213,4
                              | >120 DATA 5,167,4,147,176,214
                              | ,5,3,148,177,215,6,3,149,178
                              | ,216,7
                              | >130 DATA 5,202,2,150,179,208
                              | ,6,3,151,180,209,5,3,152,181
                              | ,210,4
                              | >140 DATA 5,133,3,144,182,211
                              | ,5,3,145,183,212,6,3,146,184
                              | ,213,7
                              | >150 DATA 5,164,2,147,176,214
                              | ,6,3,148,177,215,5,3,149,178
                              | ,216,4
Line 160 ends sound list.    | >160 DATA 5,197,1,150,179,208
                              | ,5,3,151,180,209,6,3,152,181
                              | ,210,7,3,159,191,223,0
Line 170 reads list into B and| >170 A=A+1 :: READ B :: CALL
A is counter                 | POKEV(A,B)
Line 180 checks end of list? | >180 IF B=0 THEN 190 ELSE 170
Line 190 shows how to access. | >190 PRINT "TYPE:": :CALL IO(
                              | 1,8192)"
                              | >200 CALL IO(1,8192)
                              |
Line 310 continues AD loop.  | >310 NEXT AD
Line 320 executes sound list. | >320 CALL IO(1,4096)
Line 330 prints out suggestion| >330 PRINT "CRASH": : "TYPE:":
on how to test IO.          | "CALL IO(1,4096)"

```

---

### Programs

```

Line 100 clears the screen. | >100 CALL CLEAR ! CRASH
Line 110 to ...             | >110 DATA 2,228,242,5
                             | >120 DATA 2,228,240,18
                             | >130 DATA 2,228,241,16
                             | >140 DATA 2,228,242,14
                             | >150 DATA 2,228,243,12
                             | >160 DATA 2,228,244,10
                             | >170 DATA 2,229,245,9
                             | >180 DATA 2,229,246,8
                             | >190 DATA 2,229,247,7
                             | >200 DATA 2,229,248,6
                             | >210 DATA 2,229,249,5
                             | >220 DATA 2,230,250,4
                             | >230 DATA 2,230,251,3
                             | >240 DATA 2,230,252,2
                             | >250 DATA 2,230,253,1
                             | >260 DATA 2,230,254,1
Line 270 ends sound list.   | >270 DATA 1,255,0,0
Line 280 AD is VDP address to | >280 FOR AD=4096 TO 4160 STE
start with and ends with.    | P 4
Line 290 reads list.         | >290 READ V1,V2,V3,V4
Line 300 moves them into VDP. | >300 CALL POKEV(AD,V1,V2,V3,V
                             | 4)
Line 310 continues AD loop.   | >310 NEXT AD
Line 320 executes sound list. | >320 CALL IO(1,4096)
Line 330 prints out suggestion | >330 PRINT "CRASH": ":"TYPE:":
on how to test I0.           | "CALL IO(1,4096)"

```

All data values must be converted to Binary in order to see what is going on. You now have all the data that I have as to this phase of I0 types 0 and 1. See Editor Assembler Manual also for more data on sound lists and sound chip.



-----  
 Sound table creator for conversion of sound data.

```

100 CALL CLEAR :: PRINT "*SOUND DATA TABLE CREATOR*"
110 Q$="0123456789ABCDEF"
120 INPUT "GENERATOR # ?":GN
130 INPUT "DURATION ?":DUR
140 INPUT "FREQUENCY ?":FREQ
150 INPUT "VOLUME ?":VOL :: PRINT : :
160 IF DUR>17 THEN 180
170 DUR=17
180 REM DURATION
190 DUR=INT((DUR*255)/4250) :: CONV=DUR :: GOSUB 400
200 DUR$=SEG$(HX$,3,2) :: IF FREQ>-1 THEN 290
210 REM NOISE FREQUENCY
220 FR=ABS(FREQ)-1 :: FR$="E"&STR$(FR)
230 REM NOISE VOLUME
240 VOL=INT(VOL/2) :: CONV=VOL
250 GOSUB 430 :: VOL$="F"&SEG$(HX$,4,1)
260 PRINT "DATA>02";FR$;";>";VOL$;DUR$ : :
270 GOTO 360
280 REM TONE FREQUENCY
290 FR=INT((111860.8/FREQ)+.5)
300 CONV=FR :: GOSUB 400
310 FR$=SEG$(Q$,GN*2+7,1)&SEG$(HX$,4,1)&SEG$(HX$,2,2)
320 REM TONE VOLUME
330 VOL=INT(VOL/2) :: CONV=VOL :: GOSUB 400
340 VOL$=SEG$(Q$,GN*2+8,1)&SEG$(HX$,4,1)
350 PRINT "DATA>03";SEG$(FR$,1,1)&SEG$(FR$,2,1);";>";
SEG$(FR$,3,2);VOL$;";>";DUR$;"00" : :
360 PRINT: "ANOTHER SOUND (Y/N)?"
370 CALL ONKEY("YN",3,K,S) GOTO 100,390
380 GOTO 370
390 CALL CLEAR :: END
400 REM DECIMAL TO HEX
410 AY=INT(CONV)/16 :: BY=INT(AY)/16
420 CY=INT(BY)/16 :: DY=INT(CY)/16
430 AP=(AY-INT(AY))*16 :: BP=(BY-INT(BY))*16
440 CP=(CY-INT(CY))*16 :: DP=(DY-INT(DY))*16
450 HX$=SEG$(Q$,DP+1,1)&SEG$(Q$,CP+1,1)&
SEG$(Q$,BP+1,1)&SEG$(Q$,AP+1,1) :: RETURN

```

Use this program to create Hex strings that can use  
 CALL MOVES to move strings into VDP to be played from  
 a CALL IO(1,VDP-address)

---

 CRU ACCESS INSTRUCTION

Format            CALL IO(type,bits,cru-base,variable,variable  
                  [,...])

The IO types 2 and 3 can be used to control devices. IO always must be the CRU address divided by 2 as any value above 8192 will be out of range. The cru-base must be divided by 2 as the 9901 chip ignores the least significant bits of the base register it uses. See Editor Assembler Manual page 61. The CRU data to be written should be right justified in the byte or word. The least significant bit will output to or input from the CRU address specified by the CRU base address. Subsequent bits will come from or go to sequentially higher CRU addresses. If the CRU input reads less than 8 bits, the unused bits in the byte are reset to zero. If the CRU input reads less than 16 bits but more than 8 bits, the unused bits in the full two 8 bit bytes will be reset to zero.

## Programs

Line 100 display what it does for you.	>100 DISPLAY AT(1,1)ERASE ALL   : "THIS PROGRAM CHECKS FOR      UNUSUAL KEYS BEING PRESSED      , EVEN IF MORE THEN FOUR KEY      ARE BEING PRESSED AT ONCE"
Line 110 scans CRU at >0006 and reports keys pressed.	>110 CALL IO(2,16,3,A,B):: IF      A=18 AND B=255 THEN 110 ELS      E CALL HPUT(24,3,RPT\$(" ",30      ),24,24,STR\$(A)&" "&STR\$(B))
Line 120 more reports.	>120 IF A=146 THEN CALL HPUT(      24,3,"FUNCTION KEY")ELSE IF      B=191 THEN CALL HPUT(24,3,"C      ONTROL KEY")ELSE IF B=223 TH      EN CALL HPUT(24,3,"SHIFT KEY      ")
Line 130 still more reports.	>130 IF B=251 THEN CALL HPUT(      24,3,"ENTER KEY")ELSE IF B=2      53 THEN CALL HPUT(24,3,"SPAC      E BAR")ELSE IF B=254 THEN CA      LL HPUT(24,3,"PLUS/EQUAL KEY      ")
Line start over scan of keys.	>140 GOTO 110

### Programs

```

Line 100 clears screen.      | >100 CALL CLEAR
Line 110 explains program.   | >110 CALL HPUT(4,7,"This is a
                             |   demo of the",6,7,"CALL IO(3
                             |   ,8,2176,B)",8,7,"3 = TYPE(CR
                             |   U output)",10,7,"8 = NUMBER
                             |   OF BITS",12,7,"2176=address/
                             |   2")
Line 120 turn off card, show | >120 CALL IO(3,8,2176,0):: FO
the present byte value being |   R B=0 TO 255 :: CALL HPUT(14
sent.                        |   ,7,"B=byte (value "&STR$(B)&
                             |   ")")
Line 130 display block to get | >130 CALL HPUT(18,5,"*****
attention.                   |   *****",19,5,"WA
                             |   TCH THE DRIVE LIGHTS",20,5,"
                             |   *****")
Line 140 send byte to card and | >140 CALL IO(3,8,2176,B):: NE
when done with loop, clear for |   XT B :: CALL HCHAR(14,24,32,
starting over program.       |   7):: GOTO 110
                             |
Line 100 explains program.   | >100 ! TURNS OFF/ON/OFF EACH
                             |   CARD FROM >1000 TO >1F00 BUT
                             |   WILL LOCKUP WITH CERTAIN
                             |   CARDS.
Line 110 cru address from    | >110 FOR CRU=2048 TO 3968 STE
>1000 to >1F00, turn off card, |   P 128::CALL IO(3,8,CRU,0,3,8
turn on card, delay for 2     |   >,CRU,255)::FOR A=1 TO 200::N
seconds, turn off card, turn  |   EXT A::CALL IO(3,8,CRU,0)::N
off card. Loop end.          |   EXT CRU

```

### Options

Some CRU address are used by the Operating System or XB and any attempt to redefine them will create problems. Also some of the address areas will return incorrect values as they have changed since I0 has accessed them. These problems will never become completely apparent at first, so take care. Additionally some cards have the same problem, if the card has a program that has a interrupt or CRU links turned on as you access it, a complete lock up will result as a fight for control ensues. So with that happy thought, a alternate way is to use EXECUTE or LINK instead.

-----  
CASSETTE INPUT/OUTPUT/VERIFY INSTRUCTION

Format            CALL IO(type,length,vdp-address[,...])

The three different cassette I/O instructions use the same format. The write and read instructions physically perform Input/Output to the cassette. The verify instruction will read a tape and compare it, byte by byte, against what is in the specified VDP area. All will report an I/O error if one is detected. No prompts are present with these three formats. These three types control the cassette directly so no prompt will tell the user to turn on or off the cassette record/play buttons. The programmer must inform the user with own prompt.

## Programs

(Presently I have no cassette to write programs with.)

## AUDIO GATE

-----

CRU bit 24 is the audio gate which allows data being read to be heard. If the bit is set to 1, the data being read is heard, and if the bit is set to 0, the data is not heard. Setting the bit to a 0 or 1 is done with an IO instruction, or a Assembly instruction.

## MOTOR CONTROL

-----

There are two CRU bits (22 and 23) used to control cassettes 1 and 2, respectively. When there is no Cassette IO being done, both motors remain on. When Cassette IO is specified, the DSR (Device Service Routine) will control the data being read. If there are two motor units connected, the data will be read simultaneously, or you may have the option of reading data from one motor unit and playing the recorded voice from another motor unit through the TV (Monitor) speaker.

## *NOTE:

Compatibility with or without 32K or other devices is not a concern as IO needs no RAM to work with. Therefore from just a console all IO commands will work fine. If you only have a Cassette and RXB you can quickly load/save/verify without menus, or just make up your own.

Format           CALL ISROFF(numeric-variable)

#### Description

The Interrupt Service Routine (ISR) is a routine that executes during timed intervals. The operating system of the TI is set up for these. Mouse or Screen dumps or Hot Key programs bring to mind the common uses of a ISR hook. The ISROFF routine in RXB does as it suggests and turns the ISR hook off. But the numeric-variable is used to store the address of where this ISR hook came from. Of course ISRON is the opposite and will turn it back on. Extreme care must be used when turning on or off the ISR. A PEEK at hex >83C4 (decimal -31804 and -31805) will be 0 when there is no ISR. Otherwise any other value will mean that a ISR is being used.

#### Programs

```
This line checks ISR hook.      | >100 CALL ISROFF(J)
This shows if ISR is in use.    | >110 IF J THEN PRINT "ISROFF"
This line loads another file.   | >120 CALL LOAD("DSK1.HOT")
This starts another ISR.        | >130 CALL LINK("START")
This line checks ISR hook.      | >140 CALL ISROFF(K)
This shows if ISR is in use.    | >150 IF K THEN PRINT "ISROFF"
This turns first ISR back on.   | >160 CALL ISRON(J)
This turns second ISR back on. | >170 CALL ISRON(K)
  The program continues...      |
                                |
Safer way to check ISRHOOK      | >100 CALL PEEK(-31804,I,J)
Check if zero then no ISR ON    | >110 IF I+J THEN CALL ISROFF
if I+J<>0 then turn off ISR     | (N)
and put into variable N         |
                                |
```

The above program has loaded N with the ISR HOOK Address.

Format           CALL ISR0N(numeric-variable)

#### Description

The Interrupt Service Routine (ISR) is a routine that executes during timed intervals. The operating system of the TI is set up for these. Mouse or Screen dumps or Hot Key programs bring to mind the common uses of a ISR hook. The ISR0N routine in RXB does as it suggests and turns the ISR hook on. But the numeric-variable is used to load the address of where this ISR hook came from. Of course ISR0FF is the opposite and will turn it back off. Extreme care must be used when turning on or off the ISR. A PEEK at hex >83C4 (decimal -31804 and -31805) will be 0 when there is no ISR. Otherwise any other value will mean that a ISR is being used.

#### Programs

```

This line peeks ISR hook.      | >100 CALL PEEK(-31804,I,J)
This checks if ISR is in use, | >110 IF I+J THEN CALL ISR0FF(
and if not 0 turn off ISR.    | ADDRESS1)
This line loads another file. | >120 CALL LOAD("DSK1.HOT")
This starts another ISR.      | >130 CALL LINK("START")
This turns off ISR.          | >140 CALL ISR0FF(ADDRESS2)
This checks if old ISR is ok, | >150 IF I+J THEN CALL ISR0N(A
if yes turn it on.           | DDRESS1)
The program continues...      |
                               |
Safer way to check ISRHOOK    | >100 CALL PEEK(-31804,I,J)
Check if zero then no ISR ON  | >110 IF I+J THEN CALL ISR0N(N)
if I+J<>0 then turn off ISR   |
and put into variable N       |
                               |

```

The above program has ISR HOOK Address loaded from N.

---

Format           CALL JOYST(key-unit,x-return,y-return[,...])

Description

See EXTENDED BASIC MANUAL page 108

Except for adding auto repeat there is no changes to JOYST

Programs

The program on the right will illustrate a use of JOYST subprogram. It creates two sprites and then moves them around according to the input from the joysticks. Two players with the same input speed and motion.

```
| >100 CALL CLEAR
| >110 CALL SPRITE(#1,33,5,96,1
| 28,#2,42,2,96,128)
| >120 CALL JOYST(1,X1,Y1,2,X2,
| Y2)
| >130 CALL MOTION(#1,-Y1,X1,#2
| -Y2,X2)
| >140 GOTO 120
|
```

Format

```
CALL KEY(key-unit,return-variable,
status-variable[,...])

CALL KEY(string,key-unit,return-variable,
status-variable[,...])

CALL KEY(string-variable,key-unit,return-
variable,status-variable[,...])
```

#### Description

See EXTENDED BASIC MANUAL page 109

RXB has added auto repeat features.

Strings or string variables can now be added to KEY to lock out any other keys. The strings can be empty or up to 255 in length. The string function halts program execution unlike a normal key routine similar to ACCEPT or INPUT do.

#### Programs

This line scans both joysticks	>100 CALL JOYST(1,X,Y,2,XX,YY)
This line scans both of the	>110 CALL KEY(1,F,S,2,FF,SS)
fire buttons & split keyboard.	
Try this for fun.	>CALL KEY(CHR\$(2),0,K,S)
(HINT: FCTN 4)	
Add this line to programs.	>100 CALL KEY("YNyn",0,K,S)
Suspends program until key is	>100 CALL KEY("",0,K,S)
pressed. (any key)	
Suspends program until ENTER	>100 CALL KEY(CHR\$(13),0,K,S)
is pressed.	
Suspends program until the	>100 A\$="123"
key from string A\$ is used.	>110 CALL KEY(A\$,0,KV,STATUS)
Suspends program until YES is	>100 CALL KEY("Y",0,K1,S1,"E"
typed in.	,0,K2,S2,"S",0,K3,S3)



Format                      LIST

LIST "device name"

LIST "device name":line length:line number-  
line number

#### Description

The LIST command is the same as per Extended Basic Manual page 114. The LIST routine has been modified to allow the line length to be output to a device. The line length can only be used if a device is specified. A colon (:) must follow the line length. If not included in the LIST command, the line length is set to the default of the specified output device. The line length can range from 1 to 255. If the length specified is outside this range, a Bad Line Number Error is reported.

#### Command

```
This line outputs to a device. | >LIST "PIO":80:100-120
                                |
This a dummy line.             | >100 ! TEST OF LIST
Another dummy line.           | >110 ! TEST OF LIST
                                |
```

Format           CALL LOAD("access-name"[,address,byte][,...]  
                  [,file-field,...])

                 CALL LOAD(address,byte[,...])

#### Description

See EXTENDED BASIC MANUAL page 115 for more data. The only change is to allow a CALL LOAD to an address without having to use CALL INIT first.

#### Program

This line will load address		>100 CALL LOAD(8192,128)
8192 with 128		
Loads a 56 at address 8192		>100 CALL LOAD(8192,56,"",
then skips loading then loads		8196,78,91)
78 and 91 at 8196, and 8197		

---

Format           CALL MKDIR(pathname,directory-name[,...])

                  CALL MKDIR(string-variable,string-variable  
                  [,...])

                  CALL MKDIR(number,disk-volume-name[,...])

#### Description

The MKDIR subprogram MaKes DIRectorys on hard drives or will name a disk. The pathname determines the device used and the pathname can be up to 255 characters in length. The Myarc HFDC can only support 29 characters pathnames plus the filename of 10, so that would add up to 39 characters total. The pathname must end with a period and the filename may only be 10 characters in length. MKDIR can create up to 24 directories in 24 different drives in one command. MKDIR can also create directories then sub-directories in the same command.

#### Programs

```
This line names disk 1 NONE | >CALL MKDIR("DSK1.", "NONE")
                             |
This line creates a directory| >CALL MKDIR("WDS1.", "TEST")
named TEST on hard drive 1. |
                             |
This line creates a directory| >100 CALL MKDIR("WDS1.", "ONE"
on hard drive 1 named ONE   | , "WDS1.ONE.", "TWO", "WDS1.ONE
then creates a sub-directory| .TWO.", "THREE")
named TWO of directory ONE  |
then creates a sub-directory|
named THREE of directory ONE|
of sub-directory TWO       |
                             |
```

The above program creates a directory then sub-directory then a sub-directory of that sub-directory.

Format      CALL MOTION(#sprite-number,row-velocity,  
                  column-velocity[,...])

             CALL MOTION(ALL,row-velocity,column-velocity  
                  [,...])

             CALL MOTION(STOP[,...])

             CALL MOTION(GO[,...])

#### Description

See EXTENDED BASIC MANUAL PAGE 125 for more data. A added feature to MOTION is STOP (disable sprite movement) and GO (enable sprite movement). Also ALL that affects all sprites.

#### Programs

* See EXTENDED BASIC MANUAL.

```

The program to the right will | >100 CALL CLEAR :: X=190
will set up 3 sprites to be onl | >110 CALL SPRITE(#1,65,2,9,X,
the same vertical plane, and | 20,0,#2,66,2,9,X,30,0,#3,67,
MOTION will stop all sprites. | 2,9,X,-20,0)
GO turns on sprite motion. | >120 CALL MOTION(GO)
This is a delay loop. | >140 FOR D=1 TO 2000::NEXT D
STOP turns off sprite motion. | >150 CALL MOTION(STOP)
This is a delay loop. | >160 FOR D=1 TO 2000::NEXT D
Change #3 motion direction, GO. | >170 CALL MOTION(#3,10,10,GO)
This is a delay loop | >180 FOR D=1 TO 2000::NEXT D
Continue program. | >190 GOTO 120
|
Clear screen and set up the | >100 CALL CLEAR::A(0)=-127 ::
variables A(0) and A(1) | A(1)=127
Loop to create sprites. | >110 FOR L=1 TO 28::CALL SPRI
| TE(#L,L+65,2,L,L,-L,L) ::
| NEXT L
Use MOTION ALL to change the | >120 CALL MOTION(ALL,A(RND)*R
sprite velocities. | ND,A(RND)*RND)::GOTO 120

```

#### Options

While characters 144 to 159 are being used, you cannot use sprites. Notice that CALL MOTION(STOP,#1,44,-87) is valid.

Format      MOVE start line-end line,new start line,increment

#### Description

The MOVE command is used to move a program line or block of program lines to another location in the program. The block of lines to be moved is defined by start line number and end line number. If either of these numbers are omitted, the defaults are the first program line and the last program line. However, at least one number and a dash must be entered (both cannot be omitted), and there must be at least one valid program line between start line number and end line number. To move one both the start line number and end line number are the same. If any of the above conditions are not met, a Bad Line Number Error will be reported. The new start line number defines the new line number of the first line in the moved segment. When the block is moved it will be moved. If not, a Bad Line Number Error message is reported. This problem can be corrected by using a smaller increment, or by using RES to open up space for the segment. A Bad Line Number Error also results if the renumbering process would result in a line number higher than 32767. Although moving lines within the program does not increase the size of the program, this command does require 4 bytes of the program space for line moved. This memory use is temporary, but it must be available in order to move the block. If sufficient memory is not available a Memory Full Error results and no lines are moved. This problem can usually be worked around by moving the block a few lines at a time. Before the block of lines is moved any open files are closed and any variables are lost.

#### Commands

```

Move lines 100 thru 180 to      | >MOVE 100-180,1000,5
line 1000, increment by 5.    |
Moves lines 40 thru last line | >MOVE 40-,120,
to line 120, increment by 10. |
Moves line 150 to line 110     | >MOVE 150-150,1110
This line moves first program | >MOVE -800,32220,2
line thru line 800 to line    |
32220, and increment by 2.    |

```

Format

CALL MOVES(type\$,bytes,string-variable,string-variable[,...])

CALL MOVES(type\$,bytes,from-address,to-address[,...])

CALL MOVES(type\$,bytes,from-address,string-variable[,...])

CALL MOVES(type\$,bytes,string-variable,to-address[,...])

CALL MOVES(string-variable,number,string-variable[,...])

#### Description

The MOVES subprogram moves (copies) FROM TO the amount of bytes specified using the memory type string. MOVES does not physically move memory but copies it. MOVES can RIPPLE a byte thru memory by the from-address being one byte less than the to address. The type\$ below specifies what type of memory is being moved and to what other type of memory it is moved into. The bytes are 255 maximum if being moved into a string-variable. MOVES address range is from -32768 to 0 to 32767. As MOVES mostly works with string-variables see the Extended Basic Manual page 41. MOVES will error out with * BAD VALUE IN ###* in a program if the string variable length exceeds 255, or if the number of bytes exceeds 255.

type\$	TYPE OF MEMORY
\$	STRING-VARIABLE
V	VDP ADDRESS
R	RAM ADDRESS
G	GRAM ADDRESS

*NOTE: upper case only for type as lower case are ignored.

RAM may be moved but not into ROM, and that you may move memory into GRAM but not GROM. You can copy or move memory from ROM or GROM. Also note that any devices that use phony GRAM will not work with MOVES as these devices don't use the real GRAM/GROM. VDP address are from 0 to 16384 (>0 to >3FFF)

---

 Programs

```

Line 100 has the type$ string. | >100 X$="VV"
Line 110 thus uses type$ 0 VDP | >110 CALL MOVES(X$,767,1,0)
to VDP. 767 bytes are moved. A |
VDP from-address of 1 and a |
VDP to-address of 0. Will use |
a ripple effect of moving all |
screen bytes over one address. |
|
Line 100 copies entire screen | >100 CALL MOVES("VR",768,0,81
into lower 8K. | 92)
|
Line 110 clears the screen. | >110 CALL CLEAR
Line 120 copies entire screen | >120 CALL MOVES("VR",768,0,90
into lower 8K. | 00)
Line 130 copies from lower 8K | >130 CALL MOVES("RV",768,8192
to screen, then again. GOTO | ,0,"RV",768,9000,0) :: GOTO
makes it an endless loop. | 130
|
Line 100 sets up loop. Counts | >100 FOR G=-32768 TO 32767
from -32768 to 0 to 32767 or |
(HEX >8000 to >0000 to >7FFF) |
Line 110 move GRAM/GROM to | >110 CALL MOVES("GV",8,G,1024)
VDP. 8 bytes to be moved. GA |
is counter. 1024 is decimal |
address of space character in |
VDP pattern table. |
Line 120 completes loop. | >120 NEXT G
|
|
Loop address VDP | >100 FOR V=0 TO 16384
Load that 8 bytes into space | >110 CALL MOVES("VV",8,V,1024)
Loop back | >120 NEXT V
|
|
Loop address RAM | >100 FOR R=_32768 to 32767
Load that 8 bytes into space | >110 CALL MOVES("RV",8,R,1024)
Loop back | >120 NEXT R

```

### Programs

```

Line 100 sets string-variable. | >100 I$=RPT$("I",255)
Line 120 type$ specifies I$   | >110 CALL MOVES("$V",55,I$,0)
to VDP. 55 bytes are moved.  |
Line 120 copies string J$ to  | >120 CALL MOVES("$R",255,J$,8
into lower 8K, then string I$ | 192,"$R",255,I$,8492)
into lower 8K.                |
Line 130 copies string I$ to  | >130 J$=I$ :: PRINT J$ : : I$
into J$. Eliminates old J$.   |
Then prints them.            |
Line 150 copies from lower 8K | >140 CALL MOVES("$R",255,8192
to J$, then from lower 8K at  | ,J$,"$R",255,8492,I$) :: PRI
8492 into I$ thus restoring   | NT J$: :I$
both strings and printing them|
thus a way to save stings.    |
                               |
Line 100 sets up loop. Counts | >100 FOR GA=-32768 TO 32767
from -32768 to 0 to 32767 or  |
(HEX >8000 to >0000 to >7FFF) |
Line 110 moves type$ GRAM/GROM | >110 CALL MOVES("$G",8,GA,H$)
to VDP. 8 bytes to be moved.  |
GA is counter. H$ is string   |
for storing data found.       |
Line 120 prints H$ on screen. | >120 PRINT H$
Line 130 next loop            | >130 NEXT GA

```

### Options

Dependent on Assembly Language programmers and the RXB programs that are developed. MOVES is good for replacing those CALL LOAD loops. It also provides a means to rewrite XB while running XB instead of rewriting MERGE files then loading them. Future devices benefit from MOVES as it can copy or move different types of memory directly from or to them.



Format                      NEW

CALL NEW

#### Description

The NEW command is the same as the EXTENDED BASIC MANUAL page 126. NEW can only be used from edit mode. But now CALL NEW can be called from program mode. As expected all values are reset and all defined characters become undefined. Any open files are closed. Characters 32 to 95 are reset to their standard definitions. The TRACE and BREAK commands are canceled. The program is erased from memory.

#### Command

The line to the right will        | >NEW  
 reset memory for XB.                |

#### Programs

The program to the right will | >100 CALL NEW  
 reset memory for XB.                |  
                                           |

---

Format           CALL ONKEY(string,key-unit,return-variable,  
                  status-variable) GOTO line-number[,...]

                  CALL ONKEY(string-variable,key-unit,  
                  return-variable,status-variable)  
                  GOTO line-number[,...]

#### Description

ONKEY compares a string or string-variable characters one at a time to the key return-variable until a match is found. The string length may be longer than the number of GOTO line-number list. But a error results if that key is pressed as no line-number corresponds with the position of the key. If the string length is less than the number of GOTO line-numbers then the extra GOTO line-numbers are not used. The position of the characters in the string correspond to the GOTO line-number in the list. i.e. string "12345" GOTO 1,2,3,4,5 in the example:

CALL ONKEY("12345",0,K,S) GOTO 10,20,30,40,50

The key pressed like say 3 means line 30 will be used.

Another example:

10 CALL ONKEY("Test",0,K,S) GOTO 22,29,34,41

If T is pressed then 22 is used.

If e is pressed then 29 is used.

If s is pressed then 34 is used.

If s is pressed then 34 is used.

---

Programs

```
This line accepts a key> | >100 CALL ONKEY("123",0,K,S)
                          |   GOTO 120,130,140
Keep scanning the key.   | >110 GOTO 100
First line.             | >120 PRINT "ONE":GOTO 100
Second line.           | >130 PRINT "TWO":GOTO 100
Third line.            | >140 PRINT "THREE":GOTO 100
                          |
Using GOSUB             | >100 GOSUB 110::GOTO 100
Key scan.              | >110 CALL ONKEY("YN",3,K,S)
                          |   GOTO 120,130
First line.            | >120 PRINT "YES":RETURN
Second line.           | >130 PRINT "NO":RETURN
                          |
```

The above program both act like ON GOTO with the key selecting in the string the position and line number.

Format           CALL PEEKG(address,numeric-variable-list[,...])

#### Description

The PEEKG command reads data from GROM into the variable(s) specified. It functions identical to the regular EXTENDED BASIC PEEK command page 143. Except it reads from GROM/GRAM. GROM or GRAM address above 32767 must be converted to a negative number by subtracting 65536 from the desired address. Use CALL HEX to do this.

#### Programs

The program to the right will	>100 CALL PEEKG(767,B)
read a byte from GROM.	
Address loop counter	>100 FOR D=-32768 TO 32767
PEEK Grom address value.	>110 CALL PEEK(D,X)
Convert to HEX	>120 CALL HEX(A,H\$,X,B\$)
Show address and value.	>130 PRINT "Address: ";H\$,
	D:"VALUE: ";B\$,X
Loop.	>140 NEXT D

---

Format           CALL PEEKV(address,numeric-variable-list[,...])

#### Description

The PEEKV command reads data from VDP into the variable(s) specified. It functions identical to the regular EXTENDED BASIC PEEK command page 143. Except it reads from VDP.

The VDP address should not exceed 16384 in a TI with a 9918 VDP chip, 9938 or 9958 VDP chips can go the full 32767.

VDP addresses above 32767 must be converted to a negative number by subtracting 65536 from the desired address. Also whenever a value is peeked or poked to the screen a screen offset is present. 96 must be subtracted from or added to the value to correct it.

#### Programs

The program to the right will	>100 CALL PEEKV(767,B)
read a byte from VDP and put	
it into variable B.	
This line will print it.	>110 PRINT B-96
Address loop counter	>100 FOR D=0 TO 16383
PEEK Grom address value.	>110 CALL PEEV(D,X)
Convert to HEX	>120 CALL HEX(A,H\$,X,B\$)
Show address and value.	>130 PRINT "Address:";H\$,
	D:"VALUE:";B\$,X
Loop.	>140 NEXT D

Format                      CALL POKEG(address,numeric-variable-list[,...])

#### Description

The POKEG command writes the data in the numeric variable list to GRAM at the specified address. It functions identical to the EXTENDED BASIC command LOAD page 115. Except that it writes to GRAM. GROM or GRAM addresses above 32767 must be converted to a negative number by subtracting 65536 from the desired address. CALL HEX is recommended for this.

#### Programs

The program to the right will | >100 CALL POKEG(1001,128)  
write 128 to GRAM address 1001|  
|

---

Format           CALL POKER(vdp-number,numeric-variable[,...])

                  CALL POKER(numeric-variable,number[,...])

#### Description

The POKER command writes to vdp register a byte value. Only registers 0 to 7 are valid. The byte value ranges 0 to 255.

#### Programs

This sets text mode.	>100 CALL POKER(7,244,1,240)
This is a delay loop.	>110 FOR L=1 TO 500 :: NEXT L
This sets multi color mode	>120 CALL POKER(1,232)
This is a delay loop.	>130 FOR L=1 TO 500 :: NEXT L
This sets bit map mode.	>140 CALL POKER(0,2,1,2)
This is a delay loop.	>150 FOR L=1 TO 500 :: NEXT L
This sets normal XB mode.	>160 CALL POKER(0,0)

---

Format           CALL POKEV(address,numeric-variable-list[,...])

#### Description

The POKEV command writes data to VDP into the address specified. It functions identical to the regular EXTENDED BASIC PEEK command page 143. Except it reads from VDP.

The VDP address should not exceed 16384 in a TI with a 9918 VDP chip, 9938 or 9958 VDP chips can go the full 32767.

VDP addresses above 32767 must be converted to a negative number by subtracting 65536 from the desired address.

CALL HEX is recommended for this.

Also whenever a value is poked or peeked to the screen a screen offset is present. 96 must be subtracted from or added to the value to correct it.

#### Programs

The program to the right will | >100 CALL POKEV(767,65+96)  
write A at address 767.       |  
                                  |



**Format** CALL PROTECT(pathname,filename,number[,...])

```
CALL PROTECT(string-variable,string-variable,  
numeric-variable[,...])
```

CALL PROTECT(number,filename,number[,...])

## Description

The PROTECT subprogram protects programs or files. Pathname may be up to 255 characters in length. Pathname must end in a period. The Myarc HFDC can only support a 29 character pathname plus a 10 character filename, so that would add up to 39 characters total. The pathname must end with a period and filenames must only be 10 characters in length. The number may be 0 to 255, any number other than 0 (zero) will protect a file. 0 unprotects. Up to 14 files on 14 different drives may be accessed in one command.

File error will be returned if the device is not accessed or the file or program doesn't exist. File error will be ignored when protecting a already protected file or program. File error will be reported if the disk notch is covered.

## Programs

This line unprotects a file named A-FILENAME on RAMDISK B.

```
| >CALL PROTECT("DSKB.,"A-FILENAME,0)
```

```
Line 100 protects a file named | >100 CALL PROTECT(3,"JUNK,255
JUNK on disk drive 3          | )
```

```
Line 100 A$ is drive 2      | >100 A$="DSK2." :: O$="LOAD1"
String-variable O$ and N$ are | :: N$="filename"
loaded with filenames.      |
```

```
Line 110 protects files.      | >110 CALL PROTECT(A$,0$,1,A$,
                               | N$,1)
```

```
Line 110 unprotects file DIET | >110 CALL PROTECT("WDS1.FAT."
on hard drive 1 in directory | , "DIET",0)
named FAT                      |
```

---

Format            CALL QUITOFF

#### Description

The QUITOFF command disables the QUIT KEY. The QUIT KEY is already disabled upon entering RXB. See QUITON for more data.

#### Programs

The program to the right will | >100 CALL QUITOFF  
turn off the QUIT KEY.        |  
                                 |

---

Format            CALL QUITON

#### Description

The QUITON command enables the QUIT KEY. The QUIT KEY is already disabled upon entering RXB. QUITON makes the QUIT once again functional. You may need to use this command before running certain programs that use the QUIT key.

#### Programs

The program to the right will | >100 CALL QUITON  
turn on the QUIT KEY.        |  
                                 |

```
Format      CALL RENAME(pathname,old-filename,new-filename
            [,...])

            CALL RENAME(pathname,old-directory-name,new-di
            rectory-name[,...])

            CALL RENAME(string-variable,string-variable,
            string-variable[,...])

            CALL RENAME(number,old-filename,new-filename
            [,...])
```

### Description

The RENAME subprogram renames directories or files. Pathname may be up to 255 characters in length. Pathname must end in a period. The Myarc HFDC can only support a 29 character pathname plus a 10 character filename, so that would add up to 39 characters total. The pathname must end with a period and filenames must only be 10 characters in length. RENAME can rename up to 15 files or directories on 15 different drives all in one command. File error will be returned if the device is not accessed or the file or directory doesn't exist. File error will also be reported if renaming a protected file or directory. File error will be reported if the disk notch is covered. File error is also reported if the new-filename is already being used and is protected.

## Programs

```

This line renames a file named | >CALL RENAME("DSKC.", "A-FILEN
A-FILENAME on RAMDISK C to the | AME", "NEWNAME-1A")
new filename NEWNAME-1A |
Line 100 renames a file named | >100 CALL RENAME(2, "JUNK", "JU
JUNK to JUNK2 on disk drive 2 | NK2")
Line 100 pathname A$ | >100 A$="DSK.TRASH.":: O$="LO
String-variable O$ and N$ are | AD1" :: N$="load1"
loaded with filenames. |
Line 110 rename LOAD1 to | >110 CALL RENAME(A$, O$, N$)
load1 on disk named TRASH |
Line 110 access disk TRASH and | >120 CALL RENAME(A$, N$, O$, A$,
first renames load1 to LOAD1 | O$, N$)
and renames LOAD1 to load1 |

```

Format                      RES                                      (Uses default values)

RES initial line,increment

RES initial line,increment,start line-end line

#### Description

The RES command is the same as per Extended Basic Manual page 155. The RESEQUENCE command is deleted. The abbreviation RES is the only access name. The RES command now allows a portion of the program to be resequenced. This RES DOES NOT REPLACE any undefined line numbers with 32767. Any undefined line numbers in the program are left as is. This makes it easier to fix if a problem is present.

RES cannot be used to move lines from one location to another inside a program. If the new line numbers generated by the RES command would result in a line being moved, a Bad Line Number Error is generated. A Bad Line Number Error is also reported if there are no valid program lines between start line and end line.

#### Command

```

Lines 10 to 50 are renumbered. | >RES 20,1,10-50
Line 10 becomes 20, increment |
is 1.                          |
Lines 700-800 are renumbered. | >RES ,5,700-800
Line 700 becomes 100,         |
increment is 5.               |
Lines 50-80 are renumbered.   | >RES ,,50-80
Line 50 becomes 100,          |
increment is 10. (Default)    |
Lines 1000 to last line are   | >RES 1000,,750-
renumbered. Line 750 becomes  |
1000, increment is 10.        |
Lines to 400 are renumbered.  | >RES ,20,-400
First Line becomes 100        |
(Default), increment is 20.    |
Line 40 is renumbered 20.     | >RES 20,,40
                                |

```

---

Format           CALL RMDIR(pathname,directory-name[,...])

                  CALL RMDIR(string-variable,string-variable  
                  [,...])

#### Description

The RMDIR subprogram ReMoves DIRectorys on hard drives. The pathname determines the device used and the pathname can be up to 255 characters in length. The Myarc HFDC can only support 29 characters pathnames plus the filename of 10, so that would add up to 39 characters total. The pathname must end with a period and the directory may only be 10 characters in length. RMDIR can remove up to 24 directories in 24 different drives in one command. RMDIR can also remove sub-directories then directories in the same command. Before any directory may be removed it must be empty of all files, or a error will be reported.

#### Programs

This line removes a directory| >CALL RMDIR("WDS1.", "TEST")  
named TEST on hard drive 1. |

This line removes | >100 CALL RMDIR("WDS1.ONE.TWO  
sub-directory THREE of the | ., "THREE", "WDS1.ONE.", "TWO"  
sub-directory TWO in main | , "WDS1.", "ONE")  
directory ONE then removes |  
sub-directory TWO of main |  
directory ONE then finally |  
removes directory ONE |

The above line will not work if the directory has files within a directory. CALL CUTDIR does not care though.

#### Options

HARD DRIVE ACCESS ONLY!

---

Format           CALL RMOTION(#sprite-number[,...])

                  CALL RMOTION(ALL[,...])

#### Description

The RMOTION subprogram reverses the row-velocity and column-velocity as numbers from -127 to 127. This means that RMOTION simply reverses the direction of the sprite specified so it goes in the opposite direction it was going in. This also means RMOTION ignores 0 and -128, so you can use those to bypass RMOTION if you do not want RMOTION to change the sprite. The fastest and slowest sprite speeds are never affected by RMOTION. This feature adds more power to RMOTION. The ALL feature also allows all sprites on the screen to reverse all at once. ALL may also be called as many times as wanted in a single program line. See EXTENDED BASIC MANUAL MOTION PAGE 125, SPRITE PAGE 173, DELSPRITE PAGE 75 for more data.

#### Program

RMOTION reverses the row-velocity and the column-velocity in sprite-number 1.		>100 CALL RMOTION(#1)
This line reverses the motion of all sprites.		>100 CALL RMOTION(ALL)
Line 100 sets up a sprite.		>100 CALL SPRITE(#1,33,2,96,1
		8,99,84)
Line 110 waits for a number higher than .8 randomly.		>110 IF RND<.8 THEN 110
Line 120 reverses the motion of the sprite.		>120 CALL RMOTION(#1)
Continues the program.		>130 GOTO 110

#### Options

While characters 144 to 159 are being used, you cannot use sprites.

---

Format RND

#### Description

The RND subprogram in RXB has been replaced with a TI BASIC version as the normal XB RND subprogram is hindered with so much Floating Point as to make it 3 times slower than the TI BASIC version of RND. Extensive testing proves that the new RXB RND is many times faster than the previous version.

There will actually be some programs expecting a particular RND pattern of random numbers that will no longer work the same as a result of this change. But games will appear more random than normal Extended Basic.

The RANDOMIZE seed still works but the results of the that pattern of random numbers will be different than normal XB, thus unless absolutely required will be a bigger benefit than the cost of this XB previous feature.

#### Program

```
RND example to prove speed    | >100 DIM N(100)
Counter in a FOR loop        | >110 FOR X=1 TO 100
Load Array with random numbers| >120 N(X)=RND
Show that number              | >130 PRINT N(X)
Repeat loop till done         | >140 NEXT X
```

Run this above example in TI BASIC, XB and RXB 2015 to show game type results of program results with new RND

#### Options

Random Music programs will sound very very fast.



Format

SAVE DSK3.PRGM

SAVE DSK2.PRGM,IV254

#### Description

The SAVE command functions normally to save XB programs. An additional freature is IV254 may be specified after the SAVE command to convert to Internal Variable 254 format. The IV254 format makes it much more easy to tell an XB program from EA programs when cataloging a disk. Internal Variable files do take up one sector more then XB program format. It should be noted that XB programs smaller then 3 sectors can not be saves in IV254 format.

#### Command

Saves to DISK 2 in XB program		>SAVE DSK2.TEST
image format TEST		
Saves to disk 3 in XB program		>sAVE DSK3.STUFF,IV254
Internal Variable 254 named		
STUFF		
Saves to WDS1 in dirctory EXB		>SAVE WDS1.EXB.RB,IV254
XB program Internal Variable		
254 named RB		

#### Options

Allows better cataloging options for saving XB files.

---

Format           CALL SCSI(pathname,string-variable,...)]

#### Description

The SCSI subprogram fetches a 44 byte package from the SCSI card and puts it into a string variable. This 44 byte package consists of 8 bytes internal, 8 bytes vendor ID, 16 bytes of product ID, 4 bytes revision value, 32 bit number of sectors, and 32 bit sector size. The pathname must end with a period.

#### Programs

This line gets the 44 byte     | >CALL SCSI("SCS1.",A\$)  
SCSI packet string from SCS1. |

This line gets the 44 byte     | >100 CALL ("SCS1.",X\$,"SCS3."  
SCSI packet string from SCS1, | ,Y\$,"SCS4.",Z\$)  
SCS3, and SCS4.               |

#### Options

SCSI will only access a SCSI controller. See RXB Disk Manager program for use of SCSI subprogram.

Format                      CALL SECTOR(pathname,read/write-flag,#sectors,  
sector-string,[,...])

                              CALL SECTOR(number,number,number,string  
                              [...])

                              CALL SECTOR(string-variable,numeric-variable,  
                              numeric-variable,string-variable[,...])

#### Description

The SECTOR subprogram reads or writes sectors on disk or hard drives. The pathname determines the device used and the pathname can be up to 255 characters in length. The Myarc HFDC can only support 29 characters pathnames plus the filename of 10, so that would add up to 39 characters total. The pathname must end with a period and the directory may only be 10 characters in length. The read/write-flag may be any number to read sectors and 0 will write sectors. The #sectors ranges from 1 to 32 sectors being read/written at one time. The sector-string is a Hexadecimal string of the sector to read or write. Sector-string may be a "0" or up to "FFFFFFF" or in other words in decimal form ranges from 0 to 4294967295 sectors. (2 Terabyte Hard Drive)

NOTE: The lower 8K for assembly support is used as a buffer for SECTOR so anything in the lower 8K will be corrupted. That means two things.

1. AMS support can store the sectors for duplication.
2. SECTOR is totally compatible with CORCOMP, MYARC, PARCOM, RAMDISKS, and SCSI drive controllers.

---

Programs

This line writes 1 sector 0 to drive 1 from lower 8K. | >CALL SECTOR("DSK1.",0,1,"0")

This line reads sector 0 and 1 from drive 2 to lower 8K. | >100 CALL SECTOR(2,1,2,"0")

This line puts the 2 sectors onto the screen from the lower 8K. (See MOVES for info) | >110 CALL MOVE("RV",512,8192,0)

This line reads sector 1048575| >100 CALL SECTOR("SCS1.",9, putting 32 sectors into lower 8K (32*256=8192) | 32,"FFFFF")

## Options

Only works when 32K available and destroys lower 8K data.

Format            SIZE

                 CALL SIZE

#### Description

See EXTENDED BASIC MANUAL PAGE 169 for more data.

#### Command

May only be used from command | >SIZE  
mode.                            |  
                                 |

#### Programs

May only be used from program | >100 CALL SIZE  
mode.                            |  
                                 |  
Shows memory used.            | >100 CALL SIZE  
Set up for Assembly support. | >110 CALL INIT  
Shows memory used including | >120 CALL SIZE  
Assembly space free.         |  
Set up for AMS switching.     | >130 CALL AMSINIT  
Shows memory used including | >140 CALL SIZE  
AMS amount of K and RXB banks. |

#### Options

Unless you have a 32K installed Assembly support will not work. Also unless a AMS card is installed CALL AMSINIT will not work.

---

Format           CALL SWAPCHAR(character-code,character-code  
                  [,...])

#### Description

The SWAPCHAR subprogram switches the first character-code character definition with the second character-code character definition. That means they swap definitions. The characters range from 30 to 159.

#### Programs

```
Line 100 swaps character-code | >100 CALL SWAPCHAR(65,97)
65 with character-code 97.   |
                               |
Line 100 defines character-   | >100 CALL CHAR(128,"F0F0F0F0F
code 128 and character-code   | 0F0F0F0",159,"0F0F0F0F0F0F
159.                           | 0")
Line 110 swaps them, then will| >110 CALL SWAPCHAR(128,159,32
swap space with character 128 | ,128)
Line 120 continues program.   | >120 GOTO 110
                               |
Try this one on for weird.    | >100 CALL SWAPCHAR(31,32,31,3
                               | 2)
                               | >110 CALL INVERSE(31)
                               | >120 GOTO 100
                               |
```

Description

The SWAPCOLOR subprogram swaps foreground and background colors of the first set with the second set. Or swaps the first sprite-number color with the second sprite-number color. The character-set numbers are given below:

set-number	character-codes
~~~~~	~~~~~
0	30 to 31
1	32 to 39
2	40 to 47
3	48 to 55
4	56 to 63
5	64 to 71
6	72 to 79
7	80 to 87
8	88 to 95
9	96 to 103
10	104 to 111
11	112 to 119
12	120 to 127
13	128 to 135
14	136 to 143
(also sprite table) 15	144 to 151
(also sprite table) 16	152 to 159

Programs

```
Swap foreground and background | >100 CALL SWAPCOLOR(15,5)
colors of set 15 with set 5. |
                                |
Line 100 sets up two sprites | >100 CALL SPRITE(#1,65,2,99,9
on screen.                   | 9,9,9,#2,66,16,88,88,22,33)
Line 110 swaps sprite #1 color | >110 CALL SWAPCOLOR(#1,#2)
with sprite #2 color.         |
Continue program.             | >120 GOTO 110
```

Format CALL USER(quoted-string)

 CALL USER(string-variable)

Description

The USER subprogram overrides the normal editor of edit mode of XB and reads a DV80 file into the key scan routine as if the user was keying it in.

That means Batch Processing is creating XB programs from DV80 files, Editing XB programs, MERGING, Saving, and RUNNING XB programs. Also RESequencing, adding lines, or deleting lines, and re-writing lines from the DV80 file.

Every line to be input from the DV80 file MUST END WITH A CARRIAGE RETURN! A line of input may be up to 588 characters in length. The editor will error out if the crunch buffer is full, reporting a *Line Too Long* error. (Over 163 tokens)

Other errors will be reported but will not stop the process of USER continuing to input lines. To find errors in the DV80 file the input lines are shown on screen as they are input into the editor, and errors will be reported. So you must observe the screen for errors to test the DV80 file.

USER will stop after reaching the end of the file. But USER can have its operation suspended CALL POKEV(2242,0) will halt USER and CALL POKEV(2242,9) will resume USER.

INPUT and ACCEPT will try to read from USER if it is not turned off. On the other hand DV80 files can go directly into a INPUT or ACCEPT prompts. Turn off USER to be safe though.

USER will only report errors upon opening, thus if incorrect device or filename then USER reports * USER ERROR * and just closes the USER file, thus ending operation of USER.

Example files are included with RXB to show and explain the use of USER. The batch processing USER subprogram opens a new world to the RXB programmer. Possibilities are almost endless!

Programs

This line starts USER to use		>CALL USER("DSK1.FILENAME")
Batch processing on a file		
called FILENAME		
Line 100 is same as above.		>100 CALL USER("DSK1.FILE")
but within a program.		
Line 100 variable A\$ equals a		>100 A\$="DSK.VOLUME.FILE"
String-variable path name.		
Line 110 starts USER to use		>110 CALL USER(A\$)
Batch processing on A\$		
Save this program as LOAD.		>100 CALL USER("DSK1.BATCH")

Here is an example DV80 file you save with the name BATCH.

```
! BATCH file for using
NEW and CALL FILES and RUN. cr
cr
CALL XBPGM("DSK1.A-PROGRAM",#) cr
```

The above DV80 file uses cr to mean Carriage Return. And # is for the number of files you wish open. A-PROGRAM is the name of the XB program that needs a certain number of files open.

Options

To many to list out. See BATCH for demo.

Format CALL VCHAR(row,column,character-code)

 CALL VCHAR(row,column,character-code,
 repetition[,...])

Description

See EXTENDED BASIC MANUAL page 188 for more data. The only change to VCHAR is the auto-repeat function. Notice the new auto-repeat must have the repetitions used or it gets row confused with repetitions.

Programs

This line puts character 38 at | >100 CALL VCHAR(1,1,38,99,9,1
row 1 column 1 99 times, then | ,87)
puts character code 87 at |
row 9 column 1 |
|
Fills screen with characters. | >100 CALL VCHAR(1,1,32,768,1,
| 1,65,768,1,1,97,768,1,1,30,7
| 68) :: GOTO 100
|

Format CALL VERSION(numeric-variable)

Description

See EXTENDED BASIC MANUAL PAGE 190 for more data. Also see

Programs

This line will ask for version| >CALL VERSION(X)
and return current to numeric-|
variable X. |

Line 100 asks for version num.| >100 CALL VERSION(V)
Line 110 checks for version | >110 IF V>2001 THEN INPUT "DSK
to be larger than 240 and if | NAME":D\$:: INPUT "FILENAME"
it is will ask for input to | :F\$:: CALL XBPGM("DSK."&D\$&
use a new routine CALL XBPGM. | F\$) ELSE END

Options

Will always return current version of RXB.

Format CALL VGET(row,column,length,string-variable
 [,...])

Description

The VGET subprogram returns into a string-variable from the screen at row and column. Length determines how many characters to put into the string-variable. Row numbers from 1 to 24 and column numbers from 1 to 32. Length may number from 1 to 255. If VGET comes to the edge of the screen then it wraps to the other side.

Programs

The program to the right will | >100 CALL VGET(5,9,11,E\$)
put into string-variable E\$ |
the 11 characters at row 5 and |
column 9. |

The program to the right will | >100 CALL VGET(1,3,5,M\$,9,3,1
put into string-variable M\$ | ,Q\$,24,1,32,N\$)
the 5 characters at row 1 and |
column 3, then put into |
string-variable Q\$ the 1 |
character at row 9 and column |
3, then put into |
string-variable N\$ the 32 |
characters at row 24 and |
column 1. |

Format CALL VPUT(row,column,string[,...])
 CALL VPUT(row,column,string-variable[,...])

Description

The VPUT subprogram puts a string or string-variable onto the screen at row and column. The row numbers from 1 to 24 and column numbers from 1 to 32. If the string or string-variable being put onto screen goes to an edge it wraps to the other side. Unlike the EXTENDED BASIC DISPLAY AT the VPUT subprogram will not scroll the screen.

Programs

Line 100 puts string "THIS" onl	>100 CALL VPUT(10,4,"THIS")
the screen at row 10 and	
column 4.	
Line 110 sets string-variable	>110 A\$="VPUT"
A\$ equal to string "VPUT"	
Line 120 puts string "is" at	>120 CALL VPUT(11,5,"is",10,6
row 11 and column 5, then puts	,A\$)
string-variable A\$ at row 10	
and column 6.	
Puts 456 at row 10 col 15	>100 CALL VPUT(10,15,456)

```

Format      RUN "XB"

             DELETE "XB"

             CALL CAT("XB")

             OLD XB

             SAVE XB      -(Must have a program within
                           -memory to work at all)

             CALL XB

```

Description

The XB DSR (Device Service Routine) allows access to the RXB title screen. The access will work only if the DSR is in the GPLDSR or LINK DSR. In other words, a DSR that acknowledges any type of DSR in RAM, ROM, GROM, GRAM, or VDP. Most DSR's only accept DSK or PIO. Others like the SAVE or LIST commands will only work with a program in the memory first. Still others like CALL LOAD("XB") must have the CALL INIT command used first.

From EA option 5 you may type XB then enter, or from EA option 3 type XB then enter, then enter again. If the EA option 1 (edit), then 4 (print) type XB. From TI BASIC use OLD XB or DELETE "XB".

Keep in mind that if it does not work, the problem is the DSR your using. Almost all DSR's today only acknowledge the ROM or RAM DSR's. As the XB DSR is in GROM/GRAM it seems a bit short sighted on the part of most programmers to use cut down versions of a DSR. Please discourage this as it is a disservice to us all.

Programs

The program at the right will | >100 CALL EAPGM("XB")
turn on the AUTO SELECTOR and |
wait 4 second before switching |
to the AUTO LOAD. |

This line asks for a string. | >100 INPUT A\$
This line uses the string and | >110 DELETE A\$
if you type XB then enter will |
switch to the RXB. |

This line shows the CALL XB | >CALL XB
|

Options

BASIC and EA are also available.

Format

```
CALL XBPGM("access-name")
```

```
CALL XBPGM(string-variable)
```

```
CALL XBPGM("access-name",file-number)
```

```
CALL XBPGM(string-variable,numeric-variable)
```

Description

The XBPGM subprogram is like RUN in XB. (XB manual page 161)

The RUN subprogram can't run strings so special XB loader programs were written and required. Using RUN A\$ results in a error report of * syntax error * in normal XB.

XBPGM uses quotes like RUN or strings unlike RUN. So XBPGM will run XB or BASIC programs from quoted or variables.

The file-number or numeric-variable denote the number of files to be open before the XB program is loaded and run. XBPGM first sets the number of files open, uses a NEW and then runs the access string. See FILES for more info.

If a CALL XBPGM can't find the program or disk it will close all files, clear all XB memory (Assembly lower 8K unaffected) and leave you in XB command mode. You will know this by the * Ready * and the cursor flashing below. This allows you to try again with either RUN or CALL XBPGM again.

If an empty string is used XBPGM defaults to restart the RXB title screen. See XB for more info.

Programs

The program at the right will | >100 CALL XBPGM("DSK2.HOT")
load a XB Program named HOT |
from disk drive 2 then run it. |
|
This line loads string GZ\$. | >100 GZ\$="DSK.XBGAMES.FROG"
This line uses the string path | >110 CALL XBPMG(GZ\$)
name to search all drives and |
RAMDISKS for a disk named |
XBGAMES and load a program |
named FROG then run that |
program. |
|
Line 100 should be added to | >100 CALL QUITON
most RXB program to allow the | >110 CALL XBPGM("DSKR.LOAD")
QUIT key to work for aborting |
XBPGM loader. |
|
CALL FILES(1) and run DSK1.TML | >100 CALL XBPGM("DSK1.TML",1)